



HONDA
MARINE

BF25D/BF30D Owner's Manual





Keep this owner's manual handy, so you can refer to it at any time. This owner's manual is considered a permanent part of the outboard motor and should remain with the outboard motor if resold.

The information and specifications included in this publication were in effect at the time of approval for printing. Honda Motor Co., Ltd. reserves the right, however, to discontinue or change specifications or design at any time without notice and without incurring any obligation whatever. No part of this publication may be reproduced without written permission.

INTRODUCTION

Congratulations on your selection of a Honda outboard motor. We are certain you will be pleased with your purchase of one of the finest outboard motors on the market.

We want to help you get the best results from your new outboard motor and to operate it safely. This manual contains the information on how to do that; please read it carefully.

As you read this manual you will find information preceded by a

NOTICE symbol. That information is intended to help you avoid damage to your outboard motor, other property, or the environment.

We suggest you read the warranty policy to fully understand its coverage and your responsibilities of ownership. The warranty policy is a separate document that should have been given to you by your dealer.

When your outboard motor needs scheduled maintenance, keep in mind that your Honda marine dealer is specially trained in servicing Honda outboard motors. Your Honda marine dealer is dedicated to your satisfaction and will be pleased to answer your questions and concerns.

© 2003 Honda Motor Co., Ltd. All Rights Reserved

INTRODUCTION

A FEW WORDS ABOUT SAFETY

Your safety and the safety of others are very important. And using this outboard motor safely is an important responsibility.

To help you make informed decisions about safety, we have provided operating procedures and other information on labels and in this manual. This information alerts you to potential hazards that could hurt you or others.

Of course, it is not practical or possible to warn you about all the hazards associated with operating or maintaining an outboard motor. You must use your own good judgment.

You will find important safety information in a variety of forms, including:

- **Safety Labels** — on the outboard motor.
- **Safety Messages** — preceded by a safety alert symbol  and one of three signal words, DANGER, WARNING, or CAUTION.

These signal words mean:

-  You **WILL** be **KILLED** or **SERIOUSLY HURT** if you don't follow instructions.
-  You **CAN** be **KILLED** or **SERIOUSLY HURT** if you don't follow instructions.
-  You **CAN** be **HURT** if you don't follow instructions.

- **Safety Headings** — such as *IMPORTANT SAFETY INFORMATION*.
- **Safety Section** — such as *OUTBOARD MOTOR SAFETY*.
- **Instructions** — how to use this outboard motor correctly and safely.

This entire book is filled with important safety information — please read it carefully.

CONTENTS

OUTBOARD MOTOR SAFETY	7	Gearshift/Throttle Control Lever (side-mount type)	22
IMPORTANT SAFETY INFORMATION	7	Common Controls	
SAFETY LABEL LOCATIONS	9	Power Trim/Tilt Switch (SRT and LRT types) (side-mount type)	23
CONTROLS AND FEATURES	10	(LHT type)	23
CONTROL AND FEATURE		Power Tilt Switch (LHT, SRT and LRT types).....	23
IDENTIFICATION CODES	10	Manual Relief Valve (LHT, SRT and LRT types).....	24
COMPONENT AND CONTROL LOCATIONS	11	Tilt Lock Lever (SHG, LHT, SRG, LRG, SRT and LRT types)	24
CONTROLS.....	16	Engine Cover Latches	24
SH, LH, SHG and LHT Types (long tiller handle)		Transom Angle Adjusting Rod	25
Recoil Starter Grip (SH and LH types).....	16	Trim Tab.....	25
Ignition Switch (SHG and LHT types).....	16	INSTRUMENTS.....	26
Emergency Stop Switch and Switch Clip.....	17	Trim Meter (optional equipment)	26
Throttle Grip.....	17	Tachometer (optional equipment).....	26
Throttle Friction Adjuster	18	Fuel Gauge	26
Gearshift Lever	18	INDICATORS.....	27
Steering Friction Adjuster	18	Oil Pressure Indicator.....	27
Tilt Lever		Overheating Indicator	28
(mechanical tilt/SH and LH types)	19	Cooling System Indicator	29
(gas-assisted tilt/SHG, SRG and LRG types)	19		
SRG, LRG, SRT and LRT Types (remote control)			
Ignition Switch (side-mount type).....	20		
Switch Clip and Emergency Stop Switch (side-mount type)	21		
Fast Idle Lever (side-mount type).....	21		

CONTENTS

OTHER FEATURES	29	STARTING THE ENGINE	43
Overrev Limiter.....	29	SH, LH, SHG and LHT Types	
Anodes.....	29	(long tiller handle).....	43
Portable Fuel Tank	30	SRG, LRG, SRT and LRT Types	
Fuel Cap Vent Knob	30	(remote control).....	46
Fuel Priming Bulb.....	31	EMERGENCY STARTING.....	48
INSTALLATION.....	32	STOPPING THE ENGINE.....	51
POWER REQUIREMENTS.....	32	Emergency Engine Stopping	51
BOAT TRANSOM REQUIREMENTS	32	Normal Engine Stopping.....	51
INSTALLATION POSITION	32	GEARSHIFTING AND	
ATTACHMENT	33	THROTTLE OPERATION.....	53
TRANSOM ANGLE ADJUSTMENT	34	SH, LH, SHG and LHT Types	
BATTERY CONNECTIONS.....	34	(long tiller handle).....	53
BEFORE OPERATION.....	37	SRG, LRG, SRT and LRT Types	
ARE YOU READY TO GET UNDER WAY ?	37	(remote control).....	54
IS YOUR OUTBOARD MOTOR		STEERING	55
READY TO GO ?	37	SH, LH, SHG and LHT Types	
OPERATION	39	(long tiller handle).....	55
SAFE OPERATING PRECAUTIONS	39	SRG, LRG, SRT and LRT Types	
BREAK-IN PROCEDURE.....	39	(remote control).....	55
TRANSOM ANGLE ADJUSTMENT	40	CRUISING.....	56
PORTABLE FUEL TANK.....	42	TRIM TAB.....	58
FUEL HOSE CONNECTIONS.....	42	SHALLOW WATER OPERATIONS.....	58
FUEL PRIMING.....	43	MOORING, BEACHING, LAUNCHING.....	61

CONTENTS

SERVICING YOUR OUTBOARD MOTOR.....	64	STORAGE	84
THE IMPORTANCE OF MAINTENANCE.....	64	STORAGE PREPARATION	84
MAINTENANCE SAFETY	65	Cleaning and Flushing	84
TOOL KIT AND		Fuel.....	87
EMERGENCY STARTER ROPE	66	Engine Oil	89
MAINTENANCE SCHEDULE	67	STORAGE PRECAUTIONS	89
TRIM TAB ADJUSTMENT	69	REMOVAL FROM STORAGE.....	90
MANUAL RELIEF VALVE.....	70		
ENGINE COVER REMOVAL AND		TRANSPORTING	91
INSTALLATION	70	WITH OUTBOARD MOTOR INSTALLED	
Engine Oil Level Check.....	71	ON BOAT	91
Engine Oil Change	72	WITH OUTBOARD MOTOR REMOVED	
Engine Oil Recommendations	73	FROM BOAT	92
Lubrication Points	74		
Spark Plug Service	75	TAKING CARE OF UNEXPECTED	
REFUELING.....	77	PROBLEMS.....	94
FUEL RECOMMENDATIONS.....	78	BATTERY WILL NOT CHARGE AND	
Fuel Pump Filter Inspection and Replacement.....	79	ELECTRIC STARTER WILL NOT OPERATE..	99
Portable Fuel Tank and Filter Cleaning	81	Fuse Replacement	99
Anode Replacement	82	OIL PRESSURE INDICATOR LIGHT GOES OFF	
Propeller Replacement	83	AND ENGINE SPEED IS LIMITED	100
		OVERHEATING INDICATOR LIGHT COMES	
		ON AND ENGINE SPEED IS LIMITED.....	101
		SUBMERGED MOTOR	102

CONTENTS

TECHNICAL AND CONSUMER	
INFORMATION.....	104
TECHNICAL INFORMATION.....	104
Serial Number Locations	104
Carburetor Modification for High Altitude	
Operation.....	105
Battery	105
Oxygenated Fuels.....	106
Emission Control System Information	107
Star Label	109
Specifications	111
CONSUMER INFORMATION	115
Honda Publications	115
Warranty Service Information	115
INDEX.....	116
WIRING DIAGRAMS.....	Inside Back Cover

OUTBOARD MOTOR SAFETY

IMPORTANT SAFETY INFORMATION

Honda BF25D and BF30D outboard motors are designed for use with boats that have a suitable manufacturer's power recommendation. Other uses can result in injury to the operator or damage to the outboard motor and other property.

Most accidents can be prevented if you follow all instructions in this manual and on the outboard motor. The most common hazards are discussed below, along with the best way to protect yourself and others.

Operator Responsibility

- It is the operator's responsibility to provide the necessary safeguards to protect people and property. Know how to stop the engine quickly in case of emergency. Understand the use of all controls.
- Stop the engine immediately if anyone falls overboard, and do not run the engine while the boat is near anyone in the water.
- Always stop the engine if you must leave the controls for any reason.
- Attach the emergency stop switch lanyard securely to the operator.
- Always wear a PFD (Personal Flotation Device) while on the boat.
- Familiarize yourself with all laws and regulations relating to boating and the use of outboard motors.
- Be sure that anyone who operates the outboard motor receives proper instruction.
- Be sure the outboard motor is properly mounted on the boat.
- Do not remove the engine cover while the engine is running.

OUTBOARD MOTOR SAFETY

Refuel With Care


- Gasoline is extremely flammable, and gasoline vapor can explode. Refuel outdoors, in a well-ventilated area, with the engine stopped. Never smoke near gasoline, and keep other flames and sparks away.
- Remove any portable fuel tank from the boat for refueling. Keep the portable fuel tank away from the battery or other potential spark sources.
- Refuel carefully to avoid spilling fuel. Avoid overfilling the fuel tank.
- After refueling, tighten the filler cap securely. If any fuel is spilled, make sure the area is dry before starting the engine.

Carbon Monoxide Hazard

Exhaust gas contains poisonous carbon monoxide. Avoid inhalation of exhaust gas. Never run the engine in a closed garage or confined area.

OUTBOARD MOTOR SAFETY

SAFETY LABEL LOCATIONS



(SHG, SRG and LRG types)

The labels shown here contain important safety information. Please read them carefully. These labels are considered permanent parts of your outboard motor. If a label comes off or becomes hard to read, contact an authorized Honda Marine servicing dealer for a replacement.


CONTROLS AND FEATURES

CONTROL AND FEATURE IDENTIFICATION CODES

Model		BF25D								BF30D					
Type		SH	LH	SHG	LHT	SRG	LRG	SRT	LRT	LH	SHG	LHT	LRG	SRT	LRT
Shaft Length	S	●		●		●		●			●			●	
	L		●		●		●		●	●		●	●		●
Long Tiller Handle		●	●	●	●				●	●	●	●			●
Remote Control						●	●	●	●				●	●	●
Recoil Starter		●	●							●					
Electric Starter				●	●	●	●	●	●		●	●	●	●	●
Mechanical Tilt		●	●							●					
Gas-assisted Tilt				●		●	●				●		●		
Power Trim/Tilt					●			●	●			●		●	●
Tachometer (optional equipment)				●	●	●	●	●	●		●	●	●	●	●
Trim Meter (optional equipment)								●	●					●	●
Battery charging DC receptacle		●	●							●					


Refer to this chart for an explanation of the Type Codes used in this manual to identify control and feature applications.

TYPE CODE (Example)






CONTROLS AND FEATURES

COMPONENT AND CONTROL LOCATIONS SH, LH, SHG and LHT Types (long tiller handle)




CONTROLS AND FEATURES




CONTROLS AND FEATURES

SRG, LRG, SRT and LRT Types (remote control)




CONTROLS AND FEATURES


Remote Control box (side-mount type)




Fuel Tank



**Tachometer
(optional equipment)**



**Trim Meter
(optional equipment)**




CONTROLS AND FEATURES

CONTROLS

**SH, LH, SHG and LHT Types
(long tiller handle)**


***Recoil Starter Grip
(SH and LH types)***



Pull the starter grip to operate the recoil starter for starting the engine manually.

The engine will not start unless the gearshift lever (p. 18) is in the N (neutral) position, and the clip is in the engine stop switch.

***Ignition Switch
(SHG and LHT types)***





The ignition switch controls the ignition system and starter motor.

Turning the ignition switch key to the START position operates the starter motor. The key automatically returns to the ON position when released from the START position.

The ignition switch can be used to operate the starter motor only when the gearshift lever (p. 18) is in the N (neutral) position, and the switch clip is in the emergency stop switch.

Turning the ignition switch to the OFF position stops the engine.

Emergency Stop Switch and Switch Clip




The switch clip must be inserted in the engine stop switch in order for the engine to start and run. The lanyard should be attached to the operator's PFD (Personal Flotation Device) or worn around the wrist as shown.

When used as described, the emergency stop switch and lanyard system stops the engine if the operator falls away from the controls.

A spare switch clip is supplied with the tool kit (p. 66).

Throttle Grip




The throttle grip controls engine speed.

An index mark on the tiller arm shows throttle position and is helpful for setting the throttle correctly when starting (p. 44).

CONTROLS AND FEATURES

Throttle Friction Adjuster




The throttle friction adjuster adjusts resistance to throttle grip rotation.

Turn the adjuster clockwise to increase friction for holding a throttle setting while cruising.

Turn the adjuster counterclockwise to decrease friction for easy throttle grip rotation.

Gearshift Lever




The gearshift lever is used to select F (forward), N (neutral), or R (reverse) gears.

The engine can be started with the gearshift lever in the N (neutral) position only.


Steering Friction Adjuster

(SH and LH types)



(SHG and LHT types)


STEERING FRICTION ADJUSTER



The steering friction adjuster adjusts steering resistance.

Less friction allows the outboard motor to turn more easily. More friction helps to hold steady course while cruising or to prevent the outboard motor from swinging while trailering the boat.

Tilt Lever (mechanical tilt/SH and LH types)




TILT LEVER

The tilt lever enables the outboard motor to be raised for shallow water operation, beaching, launching, or mooring.

To tilt, move the lever to the TILT position, then raise the outboard motor until the tilt mechanism engages at 30°, 45°, 75° (p. 60 and 61).

(gas-assisted tilt/SHG, SRG and LRG types)



TILT LEVER


Moving the tilt lever to the TILT position allows the outboard motor to be tilted and moving the tilt lever to the RUN (LOCK) position locks the outboard motor in the desired position. Use the tilt lever to temporarily tilt the outboard motor when the boat is operating in shallow water, or mooring in shallow water. The tilt lever must be in the RUN (LOCK) position before operating the outboard motor or the motor could tilt up when operating in reverse.

CONTROLS AND FEATURES

SRG, LRG, SRT and LRT Types (remote control)

For panel-mount or top-mount remote control information, refer to the instructions provided with the remote control equipment.

Ignition Switch (side-mount type)



The ignition switch controls the ignition system and starter motor.



Turning the ignition switch key to the START position operates the starter motor. The key automatically returns to the ON position when released from the START position.

The ignition switch can be used to operate the starter motor only when the gearshift lever (p. 22) is in the N (neutral) position, and the switch clip is in the emergency stop switch.

Turning the ignition switch to the OFF position stops the engine.

Switch Clip and Emergency Stop Switch (side-mount type)


EMERGENCY STOP SWITCH




The switch clip must be inserted in the emergency stop switch in order for the engine to start and run. The lanyard must be attached to the operator's PFD (Personal Flotation Device) or worn around the wrist as shown.

When used as described, the emergency stop switch and lanyard system stops the engine if the operator falls away from the controls.

A spare switch clip is stored in a slot in the control housing (optional equipment).



Fast Idle Lever (side-mount type)



The fast idle lever is used to set idle speed during warm-up.

The lever will not move unless the gearshift/throttle control lever is in the N (neutral) position. Conversely, the gearshift/throttle control lever will not move unless the fast idle lever is in the lowest position.


Leave the fast idle lever in the START position to provide a rich fuel mixture for starting a cold engine.

Lift the fast idle lever to warm up a cold engine after starting and to start a warm engine.

CONTROLS AND FEATURES


Gearshift/Throttle Control Lever (side-mount type)

GEARSHIFT/THROTTLE CONTROL LEVER



The control lever automatically locks itself in the N (neutral) position. To move the lever out of the N (neutral) position, you must squeeze the neutral release lever on the underside of the lever handle.

GEARSHIFT/THROTTLE CONTROL LEVER



The gearshift/throttle control lever controls engine speed and selects F (forward), N (neutral), or R (reverse) gears.

Moving the control lever 30° from N (neutral) selects the gear, and further movement increases engine speed.


A friction adjuster near the base of the control lever adjusts the operating resistance of the control lever (p. 54).

Less friction allows easier control lever movement. More friction helps to hold a steady throttle setting while cruising.


Common Controls

Power Trim/Tilt Switch

[SRT and LRT types (side-mount type)]



(LHT type)



The power trim/tilt switch is located on the control lever or the tiller handle. It is a rocker switch with UP and DN (down) positions for changing the angle of the outboard motor.


You can use the power tilt switch anytime the ignition switch is ON, whether the boat is underway or stopped.

Trim the outboard motor to obtain the best performance and stability (p. 56).

Tilt the outboard motor for shallow water operation, beaching, launching, or mooring.

Power Tilt Switch

(LHT, SRT and LRT types)



POWER TILT SWITCH


The power tilt switch is located on the engine pan. It is a rocker switch with UP and DN (down) positions for changing the angle of the outboard motor.

The power tilt switch will operate without turning the ignition switch ON.

This switch is used with the engine stopped to raise the outboard motor for mooring, trailering or maintenance.


CONTROLS AND FEATURES

Manual Relief Valve (LHT, SRT and LRT types)



The outboard motor can be tilted manually after opening the manual relief valve. This allows the outboard motor to be tilted when no battery is connected.

Tilt Lock Lever (SHG, LHT, SRG, LRG, SRT and LRT types)




The tilt lock lever is used to support the outboard motor in the fully-raised position.


When the boat is to be moored for a long time, tilt the outboard motor as far as it will go. Then move the tilt lock lever to the LOCK position, and gently lower the outboard motor until the lever contacts the stern bracket.

Engine Cover Latches

REAR




FRONT




The engine cover latches fasten the engine cover to the outboard motor.

Transom Angle Adjusting Rod (SH and LH types)




(SHG, LHT, SRG, SRT and LRT types)



The transom angle adjusting rod limits the tilt angle of the outboard motor when fully lowered.

Proper adjustment prevents the outboard motor from being trimmed too low (p. 56).

Trim Tab



The trim tab compensates for “torque steer,” which is a reaction of the outboard motor to propeller rotation.


If uncompensated, torque steer would make the outboard motor tend to turn to one side.

When the trim tab is correctly adjusted (p. 69), steering effort is equal in either direction.

CONTROLS AND FEATURES

INSTRUMENTS

Trim Meter
[optional equipment (LHT, SRT and LRT Types)]




TRIM METER

The trim meter has a range of 0° to 16° and indicates the trim angle of the outboard motor.

Refer to the trim meter when using the power trim/tilt switch to achieve proper boat performance.

Tachometer
(optional equipment)




TACHOMETER

The tachometer shows engine speed in revolutions per minute.

Refer to the tachometer when using the throttle and power trim/tilt controls to achieve the best performance from the boat.

Fuel Gauge




A fuel gauge is built into the cap of the portable fuel tank.


INDICATORS

Oil Pressure Indicator


SH and LH Types



SHG and LHT Types



SRG, LRG, SRT and LRT Types (side-mount type)



When the green light is lit, oil pressure is OK.

If oil pressure becomes low, the green light will go off, and the engine protection system will limit engine speed.


Remote controls are also equipped with a buzzer that sounds when the green light goes off.

Low oil pressure indicates that the engine oil level is low, or that there is a problem with the engine lubrication system.


CONTROLS AND FEATURES

Overheating Indicator

SHG and LHT Types



*SRT and LRT Types
(side-mount type)*




If the engine overheats, the red light will come on, and the engine protection system will limit engine speed.

Remote controls are also equipped with a buzzer that sounds when the red light comes on.

Engine overheating may be the result of clogged water intakes.

Cooling System Indicator



COOLING SYSTEM INDICATOR

Water should flow from the cooling system indicator while the engine is running. This shows that water is circulating through the cooling system.

If water stops flowing while the engine is running, that indicates a cooling system problem, such as clogged water intakes, which will cause engine overheating.

OTHER FEATURES



Overrev Limiter

The engine is equipped with an overrev limiter to prevent the possibility of mechanical damage from excessive engine speed.

The overrev limiter may be activated during operation, limiting engine speed, if the outboard motor is tilted excessively, or when propeller ventilation occurs during a sharp turn.

If the overrev limiter is activated, check the trim angle of the outboard motor.

Anodes




CONTROLS AND FEATURES

The anodes are made of a sacrificial material that helps to protect the outboard motor from corrosion.


There are two anodes on the gear case, one on the stern bracket, and another is the trim tab.

Portable Fuel Tank




The portable fuel tank has a capacity of 6.6 US gal (25 ℓ) and has a fuel gauge built into the cap.

Fuel Cap Vent Knob



The cap is provided with a vent knob to seal the portable fuel tank for carrying it to and from the boat. Open the vent knob 2 or 3 turns before starting the engine (p. 42).

Fuel Priming Bulb



A priming bulb is built into the fuel hose that connects the fuel tank to the outboard motor.

Before starting the engine, hold the priming bulb up in the direction of the arrow, then squeeze the priming bulb until it feels firm. This will ensure that fuel is supplied to the engine (p. 43).

INSTALLATION

Correct and secure installation is essential for safe boating and good performance. Follow the installation instructions provided in this manual.

POWER REQUIREMENTS


Before installation, check to be sure that the outboard motor does not exceed the recommended maximum horsepower for the boat on which it is to be installed. Refer to the boat's certification plate for recommended maximum horsepower. If the certification plate information is not available, contact the boat dealer or manufacturer.

For most applications, the outboard motor should have a horsepower rating which provides 80% of the maximum recommended horsepower for the boat.

BOAT TRANSOM REQUIREMENTS


Honda BF25D and BF30D outboard motors can be installed on a boat transom having a thickness range of 1.3 – 2.2 inches (35 – 57 mm).

INSTALLATION POSITION



Install the outboard motor on the center of the boat transom.

The antiventilation plate of the outboard motor should be 0 – 2.0 inches below the bottom of the boat.



Type	Transom Height
S	17.0 in (431 mm)
L	21.7 in (552 mm)

INSTALLATION


When the outboard motor is installed extremely low, the idle port may be immersed and the engine may become hard to start or may run poorly. Check that the idle port is high enough from the water level when the engine is stopped with the boat fully loaded.

If the outboard motor is installed too high, that will cause ventilation.

Optimum installation height varies with boat type and bottom shape. Contact the boat manufacturer for any special recommendations that are unique to a specific model of boat.

If the transom needs to be modified to accommodate the outboard motor, contact the boat manufacturer and follow their recommendations for corrective action.

ATTACHMENT



Attach the stern bracket to the boat transom by tightening the clamp screws.

Attach a rope from the boat to the hole in the stern bracket. This will help to prevent accidental loss of the outboard motor.


You may further secure the outboard motor by bolting the stern bracket to the boat transom. Use the optional mounting bolt and nut kit or other good quality stainless steel bolts, nuts, and washers. Apply silicone sealant to the bolt holes.

INSTALLATION

TRANSOM ANGLE ADJUSTMENT

Use the transom angle adjusting rod (p. 40) to adjust the angle of the outboard motor so the propeller is perpendicular to the surface of the water.

BATTERY CONNECTIONS



Honda BF25D and BF30D outboard motors produce a 12-volt, 4 or 10-ampere battery-charging current and are equipped for connection to a 12-volt battery. The battery-charging circuit is protected by a 15-ampere fuse located in the engine compartment.

The outboard motor's 12-volt output is intended for battery charging only. Lights and electrical accessories for the boat should be connected to the battery.

The battery should be kept in a corrosion-resistant battery box that is securely mounted in a location away from the fuel tank and protected from water and direct sunlight.

Types With Electric Starter


These types are equipped with battery cables. The positive (+) cable has a red band at the battery connector. The negative (-) cable has a black band at the battery connector.

For electric starter operation, use a 12-volt battery with an ampere-hour rating of at least 65 Ah (CCA 420).

Types With Recoil Starter

These types are equipped with a 12-volt DC battery-charging receptacle which can be wired to a 12-volt battery to power lights and electrical accessories for the boat.

Plug and Receptacle (types with recoil starter)



To prepare the outboard motor for connection to a battery, pull the cover out of the DC receptacle, connect your battery charging wires to the receptacle. Attach the connected DC receptacle on the holder on the tiller arm.

The receptacle is provided with a cover, which should be attached when the plug is removed, in order to keep the receptacle clean and dry.


Battery

For complete information, refer to the battery manufacturer's instructions.

Minimum Requirements

12V-65Ah (CCA 420)

Battery Terminals



Connect the positive (+) battery cable to the positive (+) battery terminal, then connect the negative (-) battery cable to the negative (-) battery terminal.

The negative (-) battery cable should always be removed from the battery when connecting or disconnecting the positive (+) battery cable, so tools cannot cause a short circuit if they touch a grounded part while being used on the positive (+) battery terminal fitting.

INSTALLATION

NOTICE

Be careful to avoid connecting the battery in reverse polarity, as that will damage the battery-charging system in the outboard motor.

BEFORE OPERATION

ARE YOU READY TO GET UNDER WAY ?

Your safety is your responsibility. A little time spent in preparation will significantly reduce your risk of injury.

Knowledge

Read and understand this manual. Know what the controls do and how to operate them.

Familiarize yourself with the outboard motor and its operation before you get under way. Know what to do in case of emergencies.

Familiarize yourself with all laws and regulations relating to boating and the use of outboard motors.

Safety

Always wear a PFD (Personal Flotation Device) while on the boat.

Attach the emergency stop switch lanyard securely to your PFD or to your wrist.

IS YOUR OUTBOARD MOTOR READY TO GO ?

For your safety, and to maximize the service life of your equipment, it is very important to take a few moments before you operate the outboard motor to check its condition. Be sure to take care of any problem you find, or have your authorized Honda Marine dealer correct it, before you operate the outboard motor.

WARNING

Improperly maintaining this outboard motor, or failing to correct a problem before operation, could cause a malfunction in which you could be seriously injured.

Always perform a preoperation inspection before each operation, and correct any problem.

Before beginning your preoperation checks, be sure the ignition switch is in the OFF position.

BEFORE OPERATION

Safety Inspection

- Look around the outboard motor for signs of oil or gasoline leaks.
- If you are using the portable fuel tank, make sure it is in good condition and properly secured in the boat (p. 42).
- Check that the fuel hose is undamaged and properly connected (p. 42).
- Wipe up any spills before starting the engine.
- Check the stern bracket to be sure the outboard motor is securely installed.
- Check that all controls are operating properly.
- Replace any damaged parts.

- Check that all fasteners are in place and securely tightened.

Maintenance Inspection

- Check the engine oil level (p. 71). Running the engine with a low oil level can cause engine damage.
- Check to be sure the propeller is undamaged, and the castle nut is secured with the cotter pin (p. 83).
- Check that the anodes are securely attached to the gear case (p. 82) and are not excessively worn. The anodes help to protect the outboard motor from corrosion.
- Make sure the tool kit and emergency starter rope are onboard (p. 66). Replace any missing items.
- Check the fuel level in the fuel tank (p. 77).
- Check that the battery fluid is between the upper and lower levels, and the battery leads are connected securely (electric starter type).

SAFE OPERATING PRECAUTIONS

To safely realize the full potential of this outboard motor, you need a complete understanding of its operation and a certain amount of practice with its controls.

Before operating the outboard motor for the first time, please review the *IMPORTANT SAFETY INFORMATION* on page 7 and the chapter titled *BEFORE OPERATION*.

For your safety, avoid starting or operating the engine in an enclosed area. Your engine's exhaust contains poisonous carbon monoxide gas which can collect rapidly in an enclosed area and cause illness or death.

BREAK-IN PROCEDURE

Break-in period: 10 hours

Proper break-in operation allows the moving parts to wear in smoothly for best performance and long service life.

First 15 minutes:

Run the engine at trolling speed. Use the minimum throttle opening necessary to operate the boat at a safe trolling speed.

Next 45 minutes:

Run the engine up to a maximum of 2,000 to 3,000 rpm, which is about 10% to 30% of maximum throttle opening.

Next 60 minutes:

Run the engine up to a maximum of 4,000 to 5,000 rpm, which is about 50% to 80% of maximum throttle opening.

Short full-throttle bursts are OK, but do not operate the engine continuously at full throttle.



For boats that plane easily, bring the boat up on plane, and then reduce the throttle opening to the recommended rpm range.

Next 8 hours:

Do not run the engine at full throttle for more than 5 minutes at a time.

OPERATION

TRANSOM ANGLE ADJUSTMENT



The transom angle adjusting rod limits the tilt angle of the outboard motor when fully lowered.

Proper adjustment prevents the outboard motor from being trimmed too low (p. 56).

To adjust, first tilt the outboard motor so it is not resting on the rod.


Push the rod in and turn the end of the rod up, so the latch will fall into line with the rod.

Remove the rod and reinsert it in the desired position.


Push the rod in and turn the end of the rod down, so the latch will fall to the locked position. Then release the rod.

NOTICE


Do not allow water to enter the idle exhaust port or the engine can be damaged.



Motor Angle Inspection (Cruising)




**INCORRECT
CAUSES BOAT TO “SQUAT”**



**INCORRECT
CAUSES BOAT TO “PLOW”**

O. K



**CORRECT
GIVES MAXIMUM PERFORMANCE**

Install the outboard motor at the best trim angle for stable cruising and maximum power.


Trim angle too large: Incorrect causes boat to “squat”.

Trim angle too small: Incorrect causes boat to “plow”.

The trim angle differs according to the combination of the boat, outboard motor, and propeller, and the operating condition.

OPERATION

PORTABLE FUEL TANK



Place the portable fuel tank in a well-ventilated location, away from direct sunlight, to reduce the possibility of a gasoline vapor explosion.

To ensure that the outboard motor will be able to draw fuel from the tank, place the tank within 6 feet of the outboard motor and not more than 3 feet below the fuel connector on the outboard motor.

Secure the portable fuel tank in the boat, so it won't move around and become damaged.

Before use, open the fuel tank vent by turning the vent knob at least 2 or 3 turns counterclockwise.

⚠ WARNING


Gasoline is highly flammable and explosive.

You can be burned or seriously injured when handling fuel.

- Stop the engine and keep heat, sparks, and flame away.
- Handle fuel only outdoors.
- Wipe up spills immediately.


FUEL HOSE CONNECTIONS

FUEL HOSE CONNECTOR



(FUEL TANK SIDE)


FUEL HOSE CONNECTOR



(OUTBOARD MOTOR SIDE)

Connect the fuel hose to the tank and the outboard motor, as shown. Be sure both connectors snap securely into place.

FUEL PRIMING




Hold the priming bulb with the outlet end higher than the inlet end. Squeeze the priming bulb several times, until it feels firm, indicating that fuel has reached the carburetor.

Check to be sure there are no fuel leaks before starting the engine.

Do not squeeze the priming bulb when the engine is running because that could flood the carburetors.

STARTING THE ENGINE

*SH, LH, SHG and LHT Types
(long tiller handle)*




1. Put the emergency stop switch clip in the emergency stop switch, and attach the lanyard to your PFD (Personal Flotation Device) or to your wrist, as shown.

The engine will not start or run, unless the clip is in the switch.

The emergency stop switch clip and lanyard system is a safety device that will stop the engine if you fall away from the controls while operating the boat.


Always attach the lanyard to your PFD, or to your wrist, before starting the engine.

OPERATION





2. Check the position of the gearshift lever. It must be in the N (neutral) position for starting.

The engine will not start if the gearshift lever is in the F (forward) or R (reverse) position.



3. Align the engine start symbol "⊗" on the tiller handle with the pointer "▶" on the throttle grip.



4. Recoil starter type:

Pull the recoil starter grip slowly until you feel resistance, then pull briskly.

Return the starter grip gently.

Electric starter type:

Turn the ignition switch key to the START position and hold it there until the engine starts.

When the engine starts, release the key, allowing it to return to the ON position.

If the engine fails to start within 5 seconds, release the key and wait at least 10 seconds before operating the starter again.

NOTICE

- *Using the electric starter for more than 5 seconds at a time will overheat the starter motor and can damage it.*
- *Turning the ignition switch key to the START position while the engine is running can damage the starter motor and flywheel.*

Also, as the engine warms up, the throttle grip can be turned to the SLOW position without stalling.

- #### 5. Before getting under way, allow the engine to warm up sufficiently to ensure good performance.

Above 41°F (5°C), warm up the engine for 2 or 3 minutes.

Below 41°F (5°C), warm up the engine for at least 10 minutes at 2,000 rpm.

During the warm-up period, check the oil pressure indicator (p. 27), overheating indicator (p. 28) and cooling system indicator (p. 29).

If the indicators show any abnormal condition, immediately stop the engine and determine the cause of the problem. Refer to *TAKING CARE OF UNEXPECTED PROBLEMS*, p. 94.


OPERATION

SRG, LRG, SRT and LRT Types (remote control)

For panel-mount or top-mount remote control information, refer to the instructions provided with the remote control equipment.

Side-Mount Type

EMERGENCY STOP SWITCH




1. Put the emergency stop switch clip in the emergency stop switch, and attach the lanyard to your PFD (Personal Flotation Device) or to your wrist, as shown.

The engine will not start or run, unless the clip is in the switch.


The emergency stop switch clip and lanyard system is a safety device that will stop the engine if you fall away from the controls while operating the boat.

Always attach the lanyard to your PFD, or to your wrist, before starting the engine.



2. Set the control lever in the N (neutral) position.

The engine will not start if the F (forward) or R (reverse) gears are engaged.




3. To start a cold engine, leave the fast idle lever in the START (fully lowered) position.

To restart a warm engine, raise the fast idle lever.

Fast idle lever cannot be raised unless the control lever is in the N (neutral) position.

The control lever cannot be moved away from the N (neutral) position unless the fast idle lever is lowered.



IGNITION SWITCH KEY

4. To start a cold engine, leave the fast idle lever in the START (fully lowered) position.


When the engine starts, release the key, allowing it to return to the ON position.

If the engine fails to start within 5 seconds, release the key and wait at least 10 seconds before operating the starter again.

NOTICE

- *Using the electric starter for more than 5 seconds at a time will overheat the starter motor and can damage it.*
- *Turning the ignition switch key to the START position while the engine is running can damage the starter motor and flywheel.*

OPERATION



5. If the fast idle lever was used to start the engine, gradually lower the lever as the engine warms up.

When the fast idle lever is fully lowered, the control lever can be moved away from the N (neutral) position.

6. Before getting under way, allow the engine to warm up sufficiently to ensure good performance.

Above 41°F (5°C), warm up the engine for 2 or 3 minutes.

Below 41°F (5°C), warm up the engine for at least 10 minutes at 2,000 rpm.


During the warm-up period, check the oil pressure indicator (p. 27), overheating indicator (p. 28), and cooling system indicator (p. 29).

If the indicators show any abnormal condition, immediately stop the engine and determine the cause of the problem. Refer to *TAKING CARE OF UNEXPECTED PROBLEMS*, p. 94.


EMERGENCY STARTING

If the battery is discharged, the starter motor is inoperative, you can start the engine manually using the emergency starter rope supplied with the motor.


(REAR)



1. Unlatch and remove the engine cover.




2. Recoil starter type:
Loosen the neutral start cable lock nut and disconnect the neutral start cable.
Remove the recoil starter assembly by unscrewing the four starter assembly bolts.



3. Set the controls the same as for normal starting (see pages 43 — 48). Use the fast idle control if needed.


Electric starter type:
Turn the ignition switch key to the ON position.



4. Set the knotted end of the emergency starter rope in the notch in the flywheel. Wind the rope clockwise around the flywheel, as shown.

OPERATION

EMERGENCY STARTER ROPE



5. Pull the emergency starter rope slowly until resistance is felt, then pull briskly.

Keep away from moving parts while pulling the rope.

If necessary, rewind the rope and pull again. If the engine does not start after several attempts, refer to *TAKING CARE OF UNEXPECTED PROBLEMS*, p. 94.

6. If the fast idle control(s) was used to start the engine, return the control(s) to the normal operating position as the engine warms up.

During the warm-up period, check the oil pressure indicator (p. 27), overheating indicator (p. 28), and cooling system indicator (p. 29).

7. Leave the recoil starter assembly off, but install the engine cover (p. 70), and lock it in place by latching the engine cover latch.

⚠ WARNING

Exposed moving parts can cause injury.

- Do not operate the outboard motor without the engine cover.
- Use extreme care when installing the engine cover.


8. If it was necessary to remove the emergency stop switch lanyard from your wrist to perform the emergency starting procedure, be sure the lanyard is attached to your wrist before operating the outboard motor.

9. Have your closest authorized Honda marine dealer check your electrical system and correct the problem, so you can use the electric starter.


STOPPING THE ENGINE

Emergency Engine Stopping

*SH, LH, SHG and LHT Types
(long tiller handle)*



*SRG, LRG, SRT and LRT Types
(remote control)*





To stop the engine in an emergency, pull the clip out of the emergency stop switch by pulling the lanyard.

We suggest that you stop the engine this way occasionally to verify that the emergency stop switch is operating properly.

Turn the engine switch key to the OFF position (electric starter type).


Normal Engine Stopping

*SH, LH, SHG and LHT Types
(long tiller handle)*



OPERATION


SRG, LRG, SRT and LRT Types (remote control)




1. Move the throttle grip to the slowest speed and control gears to N (neutral) position.

SH and LH Types (long tiller handle)


EMERGENCY STOP SWITCH



SHG and LHT Types (long tiller handle)





SRG, LRG, SRT and LRT Types (remote control)



2. Turn the ignition switch key to the OFF position to stop the engine or press the emergency stop switch until the engine stops.
3. When the boat is not in use, remove and store the ignition key and the emergency stop switch clip and lanyard.

GEARSHIFTING AND THROTTLE OPERATION


*SH, LH, SHG and LHT Types
(long tiller handle)*



To shift gears, turn the throttle grip to the SLOW position, then move the gearshift lever to select F (forward), N (neutral) or R (reverse) gears.

The engine can be started with the gearshift lever in the N (neutral) position only.

The throttle grip can be turned to the FAST position only when the gearshift lever is in the F (forward) position.



Use the throttle friction adjuster to help hold a constant throttle setting while cruising.

Turn the adjuster clockwise to increase throttle grip friction for holding a constant speed.


Turn the adjuster counterclockwise to decrease friction for easy grip rotation.

OPERATION


SRG, LRG, SRT and LRT Types (remote control)

Side-Mount Type

**CONTROL
LEVER**




**NEUTRAL
RELEASE LEVER**



To shift gears, move the control lever to select F (forward), N (neutral) and R (reverse) gears.

The control lever cannot be moved from the N (neutral) position unless the neutral release lever is squeezed.


Moving the control lever beyond the gear selection range increases engine speed.



Adjust the throttle friction adjuster so the control lever will hold a constant throttle setting while cruising.

STEERING

*SH, LH, SHG and LHT Types
(long tiller handle)*



Steer by moving the tiller handle opposite the direction you want the boat to turn.

Steering Friction Adjuster

SH and LH Types



Use the steering friction adjuster to help hold a steady course while cruising.


Move the adjuster to the LOCK direction to increase steering friction for holding a steady course.

Move the adjuster to the FREE direction to decrease friction for easy turning.

NOTICE

Do not apply grease or oil on the friction plate. Grease or oil will reduce the friction of the adjuster.

SHG and LHT Types



*SRG, LRG, SRT and LRT Types
(remote control)*

Steer the boat in the same manner as an automobile.

OPERATION

CRUISING

Engine Speed

For best fuel economy, limit the throttle opening to 80%. Use the throttle friction control (p. 53 and 54) to help you hold a steady speed.

For rough water conditions or large waves, slow down to prevent the propeller from rising out of the water.

The engine is equipped with an overrev limiter to prevent the possibility of mechanical damage from excessive engine speed.

If, for example, the outboard motor is tilted excessively, or propeller ventilation occurs during a sharp turn, the engine may overrev, activating the overrev limiter.

If engine speed becomes unstable at high speed due to activation of the overrev limiter, reduce speed and check the trim angle of the outboard motor.

Trim

SH, LH, SHG, SRG and LRG Types

Install the outboard motor at the best trim angle for stable cruising and maximum power.

Trim angle too large: Incorrect causes boat to “squat”.

Trim angle too small: Incorrect causes boat to “plow”.

It is necessary to trim the angle of the outboard motor to compensate for changes in boat load, weight distribution, water conditions, or propeller selection.

Under normal conditions, the boat

will perform best when the antiventilation plate is level with the water.

When cruising into a high wind, trim the outboard motor down slightly to level the boat and improve stability. With a tail wind, trim the outboard motor up slightly.

LHT, SRT and LRT Types

Use the power trim/tilt switch to trim the outboard motor for the best performance and stability.

You can use the power trim/tilt switch at any time, whether the boat is under way or stopped.

Press the UP or DN (down) side of the switch to adjust the angle of the outboard motor.

Refer to the trim meter (p. 26) for an indication of whether the motor is trimmed high or low.

It is necessary to trim the angle of the outboard motor to compensate for changes in boat load, weight distribution, water conditions, or propeller selection.

Under normal conditions, the boat will perform best when the antiventilation plate is level with the water.

When cruising into a high wind, trim the outboard motor down slightly to level the boat and improve stability. With a tail wind, trim the outboard motor up slightly.


NOTICE

Excessive trim/tilt angle during operation can cause propeller ventilation, overheating, and water pump damage.

LHT Type (long tiller handle)

POWER TRIM/TILT SWITCH

Press UP to trim or tilt the motor up.




Press DN to trim or tilt the motor down.

SRT and LRT Types

POWER TRIM/TILT SWITCH

Press UP to trim or tilt the motor up.




Press DN to trim or tilt the motor down.

CONTROL LEVER

MOTOR
TRIMMED TOO
LOW

MOTOR
TRIMMED TOO
HIGH




**CORRECT
GIVES MAXIMUM PERFORMANCE**

OPERATION


BOW TOO LOW DUE TO

1. LOAD IN THE FRONT
2. MOTOR TRIMMED TOO LOW




BOW TOO HIGH DUE TO

1. LOAD IN THE REAR
2. MOTOR TRIMMED TOO HIGH



TRIM TAB

If steering effort is not equal in both directions, adjust the trim tab to compensate for “torque steer,” which is the reaction of the outboard motor to propeller rotation.



Adjust the trim tab with the engine stopped. Loosen the bolt above the trim tab, turn the trim tab, then tighten the bolt securely.

When the trim tab is correctly adjusted, steering effort will be equal in both directions.

SHALLOW WATER OPERATION

LHT, SRT and LRT Types

When operating in shallow water, use the power trim/tilt switch (p. 57) to tilt the outboard motor, so the propeller and gear case won't hit the bottom.



Proceed at low speed, and monitor water flow from the cooling system indicator (p. 29) to be sure the outboard motor is not tilted so high that the water intakes are out of the water.

NOTICE

An excessive trim/tilt angle during operation can cause propeller ventilation, overheating, and water pump damage.

SHG, SRG and LRG Types

When operating in shallow water, tilt the outboard motor, using the tilt lever, so the propeller and gear case won't hit the bottom.



To tilt the outboard motor, move the tilt lever to the TILT position, then raise the outboard motor to the desired position by pulling on the engine cover grip.

NOTICE

Do not use the tiller handle as a lever to raise the outboard motor. Applying excessive force to the tiller handle can damage it.

While the outboard motor is tilted, proceed at a low speed, and do not operate the outboard motor in reverse. The outboard motor will rise suddenly if operated in reverse.

Monitor water flow from the cooling system indicator (p. 29) to be sure the outboard motor is not tilted so high the water intake is out of the water.

NOTICE


An excessive tilt angle during operation can cause propeller ventilation, overheating, and water pump damage.

To return the outboard motor to the normal operating position, move the tilt lever to the RUN (LOCK) position, you may need to raise the outboard motor slightly to disengage the tilt mechanism, then slowly lower the outboard motor.



OPERATION

SH and LH Types

When operating in shallow water, tilt the outboard motor, using the tilt lever, so the propeller and gear case won't hit the bottom.



ENGINE COVER GRIP



To tilt the outboard motor, move the tilt lever to the TILT position, then raise the outboard motor to the 30° or 45° position by pulling on the engine cover grip.

NOTICE

Do not use the tiller handle as a lever to raise the outboard motor. Applying excessive force to the tiller handle can damage it.

While the outboard motor is tilted, proceed at a low speed, and do not operate the outboard motor in reverse. The outboard motor will rise suddenly if operated in reverse.


Monitor water flow from the cooling system indicator (p. 29) to be sure the outboard motor is not tilted so high the water intake is out of the water.

NOTICE

An excessive tilt angle during operation can cause propeller ventilation, overheating, and water pump damage.

MOORING, BEACHING, LAUNCHING

SH and LH Types



To tilt the outboard motor, move the tilt lever to the TILT position, then raise the outboard motor to the 75° position by pulling on the engine cover grip as described on p. 60.

NOTICE

Do not use the tiller handle as a lever to raise the outboard motor. Applying excessive force to the tiller handle can damage it.

SHG, SRG and LRG Types

Use the tilt lever to raise and lower the outboard motor as described on p. 59.


LHT, SRT and LRT Types

To raise the outboard motor out of the water while the engine is stopped and the boat is moored, or for maximum clearance when beaching or launching, use the power tilt switch on the engine pan to tilt the outboard motor as far as it will go, move the tilt lock lever to the LOCK position, then gently lower the outboard motor until the lever contacts the stern bracket.


OPERATION

If more clearance is needed to swing the tilt lock lever into the LOCK position, rock the outboard motor back slightly by pulling on the engine cover grip.

To lower the outboard motor, tilt up, move the tilt lock lever to the FREE position, then lower the outboard motor to the desired position.



POWER TILT SWITCH




**TILT LOCK LEVER
(lock position)**

NOTICE

Do not attempt to use the power tilt switch to tilt the outboard motor down while the tilt lock lever is in the lock position. Damage to the power tilt system may occur.

RIGHT STERN BRACKET



The outboard motor can also be tilted manually after opening the manual relief valve. This feature enables the outboard motor to be tilted when no battery is connected.

For manual tilting, use a screwdriver to turn the valve counterclockwise 2 and a half turns. Close the valve firmly after positioning the engine.

Be sure the valve is closed before operating the outboard motor. If the valve is not closed, the outboard motor will tilt up when operated in reverse.

SERVICING YOUR OUTBOARD MOTOR

THE IMPORTANCE OF MAINTENANCE

Good maintenance is essential for safe, economical, and trouble-free operation. It will also help reduce air pollution.

WARNING

Improperly maintaining this outboard motor, or failure to correct a problem before operation, can cause a malfunction in which you could be seriously hurt or killed.

Always follow the inspection and maintenance recommendations and schedules in this owner's manual.

To help you properly care for your outboard motor, the following pages include a maintenance schedule, routine inspection procedures, and simple maintenance procedures using basic hand tools. Other service tasks that are more difficult, or require special tools, are best handled by professionals and are normally performed by a Honda technician or other qualified mechanic.

The maintenance schedule applies to normal operating conditions. If you operate your outboard motor under unusual conditions, consult an authorized Honda marine dealer for recommendations applicable to your individual needs and use.

Remember that your authorized Honda marine dealer knows your outboard motor best and is fully equipped to maintain and repair it.

To ensure the best quality and reliability, use only new, genuine Honda parts or their equivalents for repair and replacement.

Maintenance, replacement, or repair of the emission control devices and systems may be performed by any marine engine repair establishment or individual, using parts that are “certified” to EPA standards.

SERVICING YOUR OUTBOARD MOTOR

MAINTENANCE SAFETY

Some of the most important safety precautions follow. However, we cannot warn you of every conceivable hazard that can arise in performing maintenance. Only you can decide whether or not you should perform a given task.

WARNING

Failure to properly follow maintenance instructions and precautions can cause you to be seriously hurt or killed.

Always follow the procedures and precautions in the owner's manual.

Safety Precautions


- Make sure the engine is off before you begin any maintenance or repairs. This will eliminate several potential hazards:
 - **Carbon monoxide poisoning from engine exhaust.**
Be sure there is adequate ventilation whenever you operate the engine.
 - **Burns from hot parts.**
Let the engine and exhaust system cool before touching.
 - **Injury from moving parts.**
Do not run the engine unless instructed to do so.
- Read the instructions before you begin, and make sure you have the tools and skills required.
- To reduce the possibility of fire or explosion, be careful when working around gasoline. Use only a nonflammable solvent, not gasoline, to clean parts. Keep cigarettes, sparks, and flames away from all fuel-related parts.
- Wear gloves when handling the propeller to protect your hands from sharp edges.

SERVICING YOUR OUTBOARD MOTOR

SPARE EMERGENCY STOP SWITCH CLIP (long tiller handle type) AND EMERGENCY STARTER ROPE




SPARE EMERGENCY STOP SWITCH CLIP (long tiller handle type)




EMERGENCY STARTER ROPE

Always carry the spare emergency stop switch clip and the emergency starter rope onboard. The spare clip may either be stored in the tool bag or in an easily accessible location on the boat along with the emergency starter rope.

TOOL KIT



10 × 12 mm WRENCH



OIL CHECK SCREWDRIVER



FLAT SCREWDRIVER




PHILLIPS SCREWDRIVER



SCREWDRIVER HANDLE




PLIERS



18 × 19 mm SOCKET WRENCH



8 mm WRENCH



TOOL BAG

The above tool kit can be purchased from an authorized Honda marine dealer and may be used for simple maintenance procedures and/or emergency repairs. Keep this tool kit or an equivalent onboard, so they will always be available if you need them.

SERVICING YOUR OUTBOARD MOTOR

MAINTENANCE SCHEDULE

REGULAR SERVICE PERIOD (3) Perform at every indicated month or operating hour interval, whichever comes first.		Each use	After use	First month or 20 hrs.	Every 6 months or 100 hrs.	Every year or 200 hrs.	Every 2 years or 400 hrs.
ITEM							
•	Engine oil	Check level	○				
		Change		○	○		
	Gear case oil	Change		○ (2)	○ (2)		
•	Engine oil filter	Replace				○ (2)	
	Starter rope	Check			○		
	Timing belt	Check-adjust				○ (2)	
	Carburetor linkage	Check-adjust		○ (2)	○ (2)		
•	Idling speed	Check-adjust		○ (2)	○ (2)		
•	Valve clearance	Check-adjust		○ (2)		○ (2)	
•	Spark plug	Check-adjust			○		
		Replace				○	
	Propeller and Cotter pin	Check	○				
	Anode	Check	○				
	Lubrication	Grease		○ (1)	○ (1)		
•	Fuel tank and tank filter	Clean				○	

• Emission related items.

- (1) Lubricate more frequently when used in salt water.
- (2) These items should be serviced by an authorized Honda marine dealer, unless you have the proper tools and are mechanically proficient. Refer to the Honda shop manual for service procedures.
- (3) For professional commercial use, log hours of operation to determine proper maintenance intervals.

SERVICING YOUR OUTBOARD MOTOR

REGULAR SERVICE PERIOD (3) Perform at every indicated month or operating hour interval, whichever comes first.		Each use	After use	First month or 20 hrs.	Every 6 months or 100 hrs.	Every year or 200 hrs.	Every 2 years or 400 hrs.
ITEM							
	Thermostat	Check				○ (2)	
•	Fuel filter	Check			○		
		Replace					○
•	Fuel line	Check	○				
		Replace		Every 2 years (If necessary) (2)			
	Battery and cable connection	Check level-tightness	○				
	Bolts and nuts	Check-tightness		○ (2)	○ (2)		
•	Crankcase breather tube	Check				○ (2)	
	Cooling water passages	Clean		○ (4)			

• Emission related items.

- (1) Lubricate more frequently when used in salt water.
- (2) These items should be serviced by an authorized Honda marine dealer, unless you have the proper tools and are mechanically proficient. Refer to the Honda shop manual for service procedures.
- (3) For professional/commercial use, log hours of operation to determine proper maintenance intervals.
- (4) When operating in salt water, turbid or muddy water, the engine should be flushed with clean water after each use.

SERVICING YOUR OUTBOARD MOTOR



TRIM TAB ADJUSTMENT

The trim tab compensates for “torque steer” which is a reaction of the outboard motor to propeller rotation.

If uncompensated, torque steer would make the outboard motor tend to turn to one side.



When the trim tab is correctly adjusted, steering effort is equal in either direction.

If steering effort is unequal, loosen the trim tab bolt and adjust the angle of the trim tab. Retighten the trim tab bolt securely.



TRIM TAB TIGHTENING BOLT

If less effort is required to make left turns, move the back of the trim tab left.



TIGHTENING BOLT TRIM TAB

If less effort is required to make right turns, move the back of the trim tab right.


Adjust the trim tab in small increments, and retest steering effort with the boat evenly loaded and running at cruising speed.

SERVICING YOUR OUTBOARD MOTOR

MANUAL RELIEF VALVE

LHT, SRT and LRT Types

RIGHT STERN BRACKET



The outboard motor can be tilted manually after opening the manual relief valve. This feature enables the outboard motor to be tilted when no battery is connected.


For manual tilting, use a screwdriver to turn the valve counterclockwise 2 and a half turns. Close the valve firmly after positioning the outboard motor.

Be sure the valve is closed before operating the outboard motor. If the valve is not closed, the outboard motor will tilt up when operated in reverse.


ENGINE COVER REMOVAL AND INSTALLATION

(REAR)

ENGINE COVER LATCH



(FRONT)



The engine cover latch fastens the engine cover to the outboard motor.

To remove the engine cover, unlatch the engine cover latch, then lift the engine cover off the outboard motor.

To install the engine cover, place the cover on the outboard motor, then latch the engine cover latch securely.


SERVICING YOUR OUTBOARD MOTOR

Engine Oil Level Check

Check the engine oil level with the engine stopped and the outboard motor in the vertical position.


1. Unlatch and remove the engine cover.
2. Remove the dipstick and wipe it clean. (P.70)

OIL LEVEL DIPSTICK



3. Insert the dipstick all the way in, then remove it and check the oil level shown on the dipstick.

OIL FILLER CAP



4. If the oil level is low, remove the oil filler cap, and add oil to reach the upper limit mark shown on the dipstick. Use the oil recommended on p. 73 .

NOTICE

Running the engine with a low oil level can cause engine damage.

5. Install the oil filler cap and tighten it securely.
6. Install and lock the engine cover.


SERVICING YOUR OUTBOARD MOTOR

Engine Oil Change

An engine oil evacuation device may be used to remove the engine oil.

Drain the used oil while the engine is warm. Warm oil drains quickly and completely.

1. Unlatch and remove the engine cover (p. 70). Remove the oil filler cap.



2. Remove the engine oil drain bolt and washer.
3. Allow the used oil to drain completely, then install a new sealing washer on the engine oil drain bolt, and tighten it securely.

NOTICE

Improper disposal of engine oil can be harmful to the environment. If you change your own oil, please dispose of the used oil properly. Put it in a sealed container, and take it to a recycling center. Do not discard it in a trash bin or dump it on the ground.

SERVICING YOUR OUTBOARD MOTOR

4. With the outboard motor in a vertical position, fill to the upper limit mark on the dipstick (p. 71) with the recommended oil.

Engine oil refill capacity:

Without oil filter change:

1.7 US qt (1.6 ℓ)


With oil filter change:

2.0 US qt (1.9 ℓ)

5. Install the oil filler cap and tighten it securely.
6. Install and lock the engine cover.

Engine Oil Recommendations

Oil is a major factor affecting performance and service life. Use 4-stroke automotive detergent oil.



SAE 5W-30 is recommended for general use.

The SAE oil viscosity and service classification are in the API label on the oil container. Honda recommends that you use API SERVICE category SG, SH or SJ oil with the “starburst” certification mark displayed on the container.

SERVICING YOUR OUTBOARD MOTOR

Lubrication Points


Wipe the outside of the engine with a cloth dipped in oil. Apply marine anticorrosion grease to the following parts:

Lubrication interval:

After the first 20 hours or 1 month, then every 100 hours or 6 months. (Refer to the maintenance schedule page 67).

NOTICE

To prevent corrosion, apply anticorrosion oil to pivot surfaces where grease cannot penetrate.



Apply Honda Marine Corrosion Inhibitor (or equivalent) to all areas under the engine cover except the belts.

SERVICING YOUR OUTBOARD MOTOR


Spark Plug Service

RECOMMENDED SPARK PLUGS:
DR7EA (NGK)
X22ESR-U (DENSO)


NOTICE

Incorrect spark plugs can cause engine damage.

1. Unlatch and remove the engine cover (p. 70).
2. Disconnect the spark plug caps from the spark plugs.
3. Remove the spark plugs with a spark plug wrench.




4. Inspect the spark plugs. Replace them if the electrodes are worn, or if the insulators are cracked or chipped.



5. Measure the spark plug electrode gap with a suitable gauge. The gap should be 0.024 - 0.028 inches (0.60 - 0.70 mm).

SERVICING YOUR OUTBOARD MOTOR



6. Install the spark plugs carefully, by hand, to avoid cross-threading.

7. After each spark plug seats, tighten with a spark plug wrench to compress the sealing washer.

If reinstalling used spark plugs, tighten 1/8 - 1/4 turn after the spark plugs seat.

If installing new spark plugs, tighten 1/2 turn after the spark plugs seat.

NOTICE

Loose spark plugs can overheat and damage the engine.

Overtightening the spark plugs can damage the threads in the cylinder head.

8. Attach the spark plug caps.

9. Install and lock the engine cover.

SERVICING YOUR OUTBOARD MOTOR


REFUELING

Portable Fuel Tank


FUEL TANK CAPACITY:
6.6 US gal (25 l)

Check the fuel gauge and refill the tank when necessary.

Remove the fuel tank from the boat for refueling.




To refuel, turn the vent knob counterclockwise to the OPEN position, and unscrew the fuel tank cap.



FUEL GAUGE

SAFE FILL LEVEL



Refuel in a well-ventilated area. Fill the tank to the SAFE FILL LEVEL line.

After refueling, install the cap and tighten it securely. Turn the vent knob clockwise to the CLOSED position, and return the fuel tank to the boat.

⚠ WARNING

Gasoline is highly flammable and explosive.

You can be burned or seriously injured when handling fuel.

- Stop the engine and keep heat, sparks, and flame away.
- Handle fuel only outdoors.
- Wipe up spills immediately.

Never refill the fuel tank inside a building where gasoline fumes may reach flames or sparks. Keep gasoline away from appliance pilot lights, barbecues, electric appliances, power tools, etc.

Spilled fuel is not only a fire hazard, it causes environmental damage. Wipe up spills immediately.

SERVICING YOUR OUTBOARD MOTOR

FUEL RECOMMENDATIONS

Use unleaded gasoline with a pump octane rating of 86 or higher.

Your outboard motor is certified to operate on unleaded gasoline. Unleaded gasoline produces fewer engine and spark plug deposits and extends exhaust system life.

Never use stale or contaminated gasoline or an oil/gasoline mixture. Avoid getting dirt or water in the fuel tank.

Occasionally you may hear a light “spark knock” or “pinging” (metallic rapping noise) while operating under heavy loads. This is no cause for concern.

If spark knock or pinging occurs at a steady engine speed, under normal load, change brands of gasoline. If spark knock or pinging persists, see an authorized Honda marine dealer.

NOTICE

Running the engine with persistent spark knock or pinging can cause engine damage.

Running the engine with persistent spark knock or pinging is misuse, and the *Distributor's Limited Warranty* does not cover parts damaged by misuse.

SERVICING YOUR OUTBOARD MOTOR

Fuel Pump Filter Inspection and Replacement

The fuel pump filter is located under the engine cover between the fuel coupling and the fuel pump.


Water or sediment accumulated in the filter can cause loss of power or hard starting. To prevent engine malfunction, inspect the filter and replace when necessary.

⚠ WARNING

Gasoline is highly flammable and explosive.

You can be burned or seriously injured when handling fuel.


- Stop the engine and keep heat, sparks, and flame away.
- Handle fuel only outdoors.
- Wipe up spills immediately.



FUEL HOSE CONNECTOR


1. Disconnect the fuel hose connector from the outboard motor.

SERVICING YOUR OUTBOARD MOTOR



FUEL FILTER

2. Raise the fuel filter, and remove it from the engine under case.




HOSE CLAMP GRIPPER
(commercially available)

3. Inspect the filter for water and/or sediment accumulation.


If the filter is OK, reinstall it. If water and/or sediment are present, replace the filter as described in the following steps. Always replace the filter at the scheduled replacement interval (p. 68).

4. Place clamps on the fuel hoses on each side of the filter to prevent fuel leakage when the fuel hoses are disconnected.



FUEL FILTER

SERVICING YOUR OUTBOARD MOTOR



5. Install the new fuel filter so the arrow on the fuel filter points toward the fuel pump.

Fuel flow will be reduced if the fuel filter is installed backward.

6. Connect the fuel hoses to the fuel filter securely with the hose clips. Remove the fuel hose clamps used to close the fuel hoses.


7. Securely connect the fuel hose connector to the outboard motor (refer to page 42).
8. Prime the engine using the priming bulb (p. 43). Check for fuel leaks. Repair any fuel leaks if necessary.

If loss of power or hard starting are found to be caused by excessive water or sediment accumulation in the fuel filter, inspect the fuel tank.

Clean the fuel tank and tank filter if necessary. It may be necessary to drain the fuel tank completely and refill with fresh gasoline.

Portable Fuel Tank and Filter Cleaning


Fuel Tank



Empty the portable fuel tank into an approved gasoline container. Use a funnel to avoid spilling fuel. Rinse the fuel tank with nonflammable solvent to remove any accumulated sediment.


SERVICING YOUR OUTBOARD MOTOR

Fuel Tank Filter



1. Unscrew the fuel hose connector by turning it counterclockwise, then remove the fuel hose connector and fuel filter from the tank.
2. Clean the filter in nonflammable solvent. Inspect the fuel tank filter and the connector O-ring. Replace them if damaged.
3. Reinstall the filter and hose connector in the fuel tank. Tighten the hose connector securely.

Anode Replacement



The anodes are located on the trim tab and the stern bracket. They are made of a sacrificial material that helps to protect the outboard motor from corrosion.

Replace the anodes when they have been reduced to about half their original size, or if they are crumbling.

NOTICE

Painting or coating the anodes will defeat their purpose and will lead to rust and corrosion damage to the outboard motor. The anodes must be exposed to the water in order to protect the outboard motor.

SERVICING YOUR OUTBOARD MOTOR

Propeller Replacement

Before replacing the propeller, remove the clip from the engine stop switch to prevent any possibility of the engine being started while you are working with the propeller.

The propeller blades may have sharp edges, so wear heavy gloves to protect your hands.


Removal

Remove the cotter pin, unscrew the castle nut, remove the washer, then remove the propeller and thrust washer.

Installation

Install the propeller in the reverse order of removal.

- Install the thrust washer with the grooved side toward the gear case.
- Use a genuine Honda stainless cotter pin and bend the pin ends as shown.



STORAGE

STORAGE PREPARATION

Proper storage preparation is essential for keeping your outboard motor troublefree and looking good. The following steps will help to keep rust and corrosion from impairing your outboard motor's function and appearance, and will make the engine easier to start when you use the outboard motor again.

Cleaning and Flushing

Thoroughly clean and flush the outboard motor with fresh water after operation in dirty water or salt water.


Touch up any damaged paint, and coat areas that may rust with Honda Corrosion Inhibitor, or equivalent. Lubricate controls with a silicone spray lubricant.

Cleaning

Wash the outside of the outboard motor with clean, fresh water, and flush the cooling system as described.

Flushing With the Honda Garden Hose Adapter (optional equipment)


It is necessary to run the engine during the flushing procedure. For safety, remove the propeller from the outboard motor (p. 83).



WASH PLUG (flush plug)

1. Remove the wash plug and sealing washer from the WASH plug hole in the gear case. Be sure not to remove the oil level plug from the OIL LEVEL plug hole in the gear case.

**GARDEN HOSE ADAPTER
(FLUSH KIT COUPLER)**




2. Remove the sealing washer from the wash plug and install the sealing washer on the flush kit coupler.
3. Install the flush kit coupler into the WASH plug hole and connect a fresh water hose to the garden hose adapter.

4. Move the gearshift lever or control lever to the N (neutral) position. Flush the outboard motor in the neutral position only.
5. Turn on the fresh water supply to the flush kit coupler.

NOTICE

Running the engine without good water circulation can cause overheating and water pump damage.

Damage caused by running the outboard motor without sufficient cooling water is not covered by the *Distributor's Limited Warranty*.




COOLING SYSTEM INDICATOR

6. Start the engine. Monitor the cooling system indicator. Stop the engine if water does not come out of the cooling system indicator and check the fresh water supply. If the fresh water supply is insufficient it may be necessary to temporarily cover the three water intakes with duct tape.

STORAGE

WATER INTAKES



7. Allow the engine to run at idle for at least 5 minutes to clean the inside of the motor.
8. Stop the motor and remove the garden hose adapter.


9. Remove the sealing washer from the garden hose adapter and install the sealing washer on the wash plug.

If tape was used to cover the three water intakes in step 6, remove the tape now.

10. Install the wash plug into the gear case securely.

Flushing Without the Honda Garden Hose Adapter

It is necessary to run the engine during the flushing procedure. For safety, remove the propeller from the outboard motor (p. 83).



ANTIVENTILATION PLATE

1. Place a container under the outboard motor, and fill it with clean, fresh water. The water level must be at least 2 inches above the antiventilation plate.

NOTICE

Running the engine without good water circulation can cause overheating and water pump damage.

Damage caused by running the outboard motor without sufficient cooling water is not covered by the *Distributor's Limited Warranty*.

2. Start the engine and run in the N (neutral) position at low speed for at least 10 minutes.
3. After flushing, stop the engine, remove the water container, and reinstall the propeller (p. 83).

Fuel

Gasoline will oxidize and deteriorate in storage. Old gasoline will cause hard starting, and it leaves gum deposits that clog the fuel system. If the gasoline in your fuel tank and carburetor deteriorates during storage, you may need to have the carburetor and other fuel system components serviced or replaced.

The length of time that gasoline can be left in your fuel tank and carburetor without causing functional problems will vary with such factors as gasoline blend, your storage temperatures, and whether the fuel tank is partially or completely filled. The air in a partially filled fuel tank promotes fuel deterioration. Very warm storage temperatures accelerate fuel deterioration. Fuel deterioration problems may occur within a few months, or even less if the gasoline was not fresh when you filled the fuel tank.

Adding a Fuel Stabilizer

When adding a fuel stabilizer, fill the fuel tank with fresh gasoline. If only partially filled, air in the tank will promote fuel deterioration during storage. If you keep an additional container of gasoline for refueling, be sure that it contains only fresh gasoline.

1. Add fuel stabilizer following the manufacturer's instructions.
2. After adding a fuel stabilizer, run the engine in water for 10 minutes to be sure that the treated gasoline has replaced the untreated gasoline in the carburetor.
3. Turn the engine OFF.


STORAGE

The *Distributor's Limited Warranty* does not cover fuel system damage or engine performance problems resulting from neglected storage preparation.

Draining the Fuel System

You can avoid fuel deterioration problems by draining the fuel tank and carburetors.

1. Disconnect the fuel hose from the outboard motor.




2. With the outboard motor in a vertical position, place an approved gasoline container below the fuel drain outlet, and use a funnel to avoid spilling fuel.

⚠ WARNING

Gasoline is highly flammable and explosive.

You can be burned or seriously injured when handling fuel.

- Stop the engine and keep heat, sparks, and flame away.
- Handle fuel only outdoors.
- Wipe up spills immediately.



3. Loosen the drain screw on # 1 carburetor, allow the carburetor to drain completely, then tighten the drain screw securely.
4. Remove the drain tube from # 1 carburetor, install it on # 2 carburetor, and drain that carburetor in the same manner.

5. Repeat this procedure to drain # 3 carburetor.
6. After all three carburetors are drained, reinstall the drain tube on # 1 carburetor.
7. Drain the fuel tank into an approved gasoline container, or if you need to store fuel in the fuel tank, you can extend fuel storage life by filling the fuel tank with fresh gasoline and adding a fuel stabilizer that is formulated for that purpose.

If using the portable fuel tank, firmly close the fuel tank vent knob.


Engine Oil

1. Change the engine oil (p. 72).
2. Remove the spark plugs (p. 75), and remove the clip from the emergency stop switch.
3. Pour a tablespoon (5 — 10 cm³) of clean engine oil into each cylinder.
4. Using the emergency starter rope (p. 49), rotate the flywheel a few revolutions to distribute the oil in the cylinders.
5. Reinstall the spark plugs (p. 79).

STORAGE PRECAUTIONS

Select a well-ventilated storage area. If possible, avoid storage areas with high humidity.


If storing a container of gasoline, such as the portable fuel tank, store it away from any appliance that operates with a flame, such as a furnace, water heater, or clothes dryer. Also avoid any area with a spark producing electric motor, or where power tools are operated.



OUTBOARD MOTOR STAND

STORAGE

If the outboard motor will be removed from the boat for storage, we recommend storing it vertically by mounting it on a stand.



CASE PROTECTOR

If it is necessary to store the outboard motor horizontally, drain the carburetor (p. 88), and drain the engine oil (p. 72), before removing the outboard motor from the boat.

Position the outboard motor with its carburetor side down, and cushion it with protective packing material.

Cover the outboard motor to keep out dust. Do not use sheet plastic as a dust cover. A nonporous cover will trap moisture, promoting rust and corrosion.

REMOVAL FROM STORAGE

Check your outboard motor as described in the *BEFORE OPERATION* chapter of this manual.


If the cylinders were coated with oil during storage preparation, the engine may smoke briefly at startup. This is normal.

TRANSPORTING

WITH OUTBOARD MOTOR INSTALLED ON BOAT


When trailering a boat with the outboard motor attached, leave the engine in the normal running position, if possible.

SH, LH, SHG and LHT Types



(SH and LH types)

STEERING FRICTION ADJUSTER



TO INCREASE FRICTION (LOCK)

TO DECREASE FRICTION (FREE)

(SHG and LHT types)


Tighten the steering friction adjuster to prevent the outboard motor from moving while trailering the boat.

SRG, LRG, SRT and LRT Types (remote control)

Use a motor support bar to prevent the outboard motor from moving while trailering the boat. Refer to the manufacturer's instructions for using a motor support bar.

All Types

If there is insufficient road clearance in the normal running position, then tilt the outboard motor and use a motor support bar, or remove the outboard motor from the boat. Refer to the manufacturer's instructions for using a motor support bar.





MOTOR SUPPORT BAR (commercially available)

TRANSPORTING


WITH OUTBOARD MOTOR REMOVED FROM BOAT

Secure the outboard motor in either the vertical or horizontal position shown on p. 90.

(Tiller handle type)




CARRYING HANDLE



To carry, hold the outboard motor by the carrying handle, or hold by the carrying handle and the lug beneath engine cover lock lever, as shown.


NOTICE

Lifting the outboard motor by the engine cover, or using the installed outboard motor as a handle or lever to move the boat, can damage the outboard motor.




When transporting the outboard motor on a vehicle, perform the following.

1. Remove the engine cover, lift the outboard motor using the engine lifting eye, and place on the outboard motor stand.



2. Secure the outboard motor with the bolts and nuts.



3. Reinstall the engine cover.

When trailing or transporting the boat with the motor attached, it is recommended that the motor remain in normal running position with the steering friction adjuster locked position (p. 91).

TAKING CARE OF UNEXPECTED PROBLEMS

ELECTRIC STARTER WILL NOT OPERATE	Possible Cause	Correction
1. Check battery.	Battery connections loose or corroded.	Clean and tighten battery connections.
	Battery discharged.	Recharge battery.
2. Check fuse.	Fuse burnt out.	Replace fuse (p. 97).
3. Use emergency starting procedure (p. 48), then take outboard motor to an authorized Honda Marine dealer, or refer to the shop manual.	Starter malfunction, switch malfunction, or electrical problem in the starting circuit.	Replace or repair faulty components as necessary.

TAKING CARE OF UNEXPECTED PROBLEMS

ENGINE WILL NOT START	Possible Cause	Correction
1. Check emergency stop switch clip.	Clip not inserted in stop switch.	Insert clip in stop switch.
2. Check control positions.	Gearshift lever or control lever not in neutral position.	Shift to neutral (p. 44 and 46).
	Throttle grip not in START position (long tiller-handle type).	Turn throttle grip to START position (p. 44).
	Fast idle lever not raised (side-mount type).	Raise fast idle lever, unless engine is warm (p. 47).

TAKING CARE OF UNEXPECTED PROBLEMS

ENGINE WILL NOT START (continued)	Possible Cause	Correction
3. Check fuel.	Out of fuel.	Refuel (p. 77).
	Fuel vent closed (portable fuel tank).	Open fuel tank vent (p. 30).
	Fuel hose not primed.	Squeeze priming bulb (p. 31).
	Fuel pump filter or fuel tank filter clogged.	Replace fuel filters (p. 79 and 81).
	Bad fuel; boat stored without treating or draining gasoline, or refueled with bad gasoline.	Drain fuel tank and carburetors (p. 87 and 88). Refill with fresh gasoline (p. 77).
4. Remove and inspect spark plugs.	Spark plugs faulty, fouled or improperly gapped.	Gap or replace spark plugs (p. 75).
	Spark plugs wet with fuel (flooded engine).	Dry and reinstall spark plugs. Start engine with the throttle open.
5. Take outboard motor to an authorized Honda marine dealer, or refer to the shop manual.	Carburetor malfunction, fuel pump failure, ignition malfunction, stuck valves, etc.	Replace or repair faulty components as necessary.

TAKING CARE OF UNEXPECTED PROBLEMS

HARD STARTING OR STALLS AFTER STARTING	Possible Cause	Correction
1. Check control positions.	Throttle grip not in START position (long tiller-handle type).	Turn throttle grip to START position (p. 44).
	Fast idle lever not raised (side-mount type).	Raise fast idle lever, unless engine is warm (p. 46).
2. Check fuel.	Fuel vent closed (portable fuel tank).	Open fuel tank vent (p. 30).
	Fuel hose not primed. Fuel pump filter or fuel tank filter clogged.	Squeeze priming bulb (p. 31). Replace fuel filters (p. 79 and 81).
	Bad fuel; boat stored without treating or draining gasoline, or refueled with bad fuel.	Drain fuel tank and carburetors (p. 87 and 88). Refill with fresh gasoline (p. 77).

TAKING CARE OF UNEXPECTED PROBLEMS

HARD STARTING OR STALLS AFTER STARTING (continued)	Possible Cause	Correction
3. Remove and inspect spark plugs.	Spark plugs faulty, fouled or improperly gapped.	Gap or replace spark plugs (p. 75).
4. Take outboard motor to an authorized Honda marine dealer, or refer to the shop manual.	Carburetor malfunction, fuel pump failure, ignition malfunction, etc.	Replace or repair faulty components as necessary.

ENGINE OVERHEATS	Possible Cause	Correction
1. Check water intake screens.	Water intake screens clogged.	Clean water intake screens.
2. Take outboard motor to an authorized Honda marine dealer, or refer to the shop manual.	Faulty thermostat or water pump.	Replace or repair faulty components as necessary.

TAKING CARE OF UNEXPECTED PROBLEMS

BATTERY WILL NOT CHARGE AND ELECTRIC STARTER WILL NOT OPERATE

The battery-charging circuit and the electric starter relay circuit are protected by the 15-ampere fuse. If the fuse burns out, the engine will not charge the battery, and the electric starter will not operate. The engine can be started using the emergency starter rope.

The ignition switch is also protected by the 15-ampere fuse. If the fuse burns out, the engine will not start or run, and the power trim/tilt switch will not operate.

Fuse Replacement



1. With the engine stopped, remove the engine cover.
2. Remove the fuse cover.

3. Remove and inspect the fuse. If a fuse is burnt out, install a replacement fuse of the specified rating. The outboard motor is supplied with spare fuse in the fuse holder.

DESIGNATED FUSE: 15A, 10A

NOTICE

Never use a fuse with a rating greater than specified. Serious damage to the electrical system could result.




4. Reinstall the fuse cover and the engine cover.


Before further operation, try to determine and correct the electrical problem that caused the fuse to burn out. An uncorrected electrical problem may cause the fuse to burn out again.

TAKING CARE OF UNEXPECTED PROBLEMS


OIL PRESSURE INDICATOR LIGHT GOES OFF AND ENGINE SPEED IS LIMITED



(long tiller handle/SH and LH types)



(long tiller handle/SHG and LHT types)



If oil pressure becomes low, the green indicator light will go off, and the engine protection system will limit engine speed. If you are at cruising speed, engine speed will decrease gradually.

Remote-control type is equipped with a buzzer that sounds when the green indicator light goes off. The buzzer sound stops below an engine speed of 1,400 rpm.

Low oil pressure may be the result of a low engine oil level, or there may be a problem with the engine lubrication system.

If the throttle is closed suddenly after full throttle operation, engine speed may drop below the specified idle rpm, and that could activate the engine protection system momentarily.


If low oil pressure activates the engine protection system, stop the engine, check the engine oil level (p. 71), and add oil if needed.

With the engine oil at the recommended level, restart the engine. If the lubrication system is OK, the green indicator light should come on within 30 seconds, and the engine will respond normally to throttle grip or control lever operation.


If the engine protection system remains activated after 30 seconds, return to the nearest boat landing, and have the outboard motor inspected by an authorized Honda marine dealer.

TAKING CARE OF UNEXPECTED PROBLEMS

OVERHEATING INDICATOR LIGHT COMES ON AND ENGINE SPEED IS LIMITED



(long tiller handle/SHG and LHT types)




(remote control type)

If the engine overheats, the red indicator light will come on, and the engine protection system will limit engine speed. If you are at cruising speed, engine speed will decrease gradually.

Remote-control types are equipped with a buzzer that sounds when the red indicator light comes on.

Engine overheating may be the result of clogged water intake screens, or there may be a problem with the cooling system thermostat or water pump.



COOLING SYSTEM INDICATOR

If overheating activates the engine protection system, idle the engine in neutral, and check the cooling system indicator.

If water is flowing from the cooling system indicator, continue idling for 30 seconds. If the cooling system is OK, the red indicator light should go off within 30 seconds, and the engine will respond normally to throttle grip or control lever operation.

TAKING CARE OF UNEXPECTED PROBLEMS

If there is no water flowing from the cooling system indicator, stop the engine, and tilt the outboard motor to inspect the water intake screens. If restricted, clean the water intake screens, return the outboard motor to the running position, restart the engine, and check the cooling system indicator again.

If there is still no water flowing from the cooling system indicator, or if the engine protection system remains activated after 30 seconds, return to the nearest boat landing, and have the outboard motor inspected by an authorized Honda marine dealer.


SUBMERGED MOTOR

A submerged outboard motor must be serviced immediately after it is recovered from the water in order to minimize corrosion.

If there is a Honda marine dealer nearby, take the motor to the dealer immediately. If you are far from a dealer, proceed as follows:

1. Remove the engine cover, and rinse the outboard motor with fresh water to remove salt water, sand, mud, etc.
2. Drain the carburetors as described on p. 87 .

3. Change the engine oil as described on p. 72 — 73 . If there was water in the engine crankcase, or if the used engine oil showed signs of water contamination, then a second engine oil change should be performed after running the engine for half an hour.



EMERGENCY STARTER ROPE


4. Remove the spark plugs (p. 75), and remove the clip from the engine switch. Pull the emergency starter rope, rotate the flywheel a few revolutions to completely expel any water from the cylinders.

TAKING CARE OF UNEXPECTED PROBLEMS

If the engine was running when it submerged, there may be mechanical damage, such as bent connecting rods. If the engine binds when cranked, do not attempt to run the engine until it has been repaired.

NOTICE

When cranking the engine with an open ignition circuit (spark plugs removed from the ignition circuit), remove the clip from the emergency stop switch to prevent possible damage to the ignition system.



5. Pour a teaspoon of engine oil into each spark plug hole, then pull the recoil starter grip several times to lubricate the inside of the cylinders.
6. Reinstall the spark plugs, and put the emergency stop switch clip into the switch.

7. Attempt to start the engine.

If the engine fails to start, remove the spark plugs, dry them, then reinstall the spark plugs and attempt to start the engine again.

If the engine starts, and no mechanical damage is evident, continue to run the engine for a half hour or longer. Be sure the water level is at least two inches above the antiventilation plate to avoid overheating and water pump damage.


8. As soon as possible, take the outboard motor to an authorized Honda marine dealer for inspection and service.

TECHNICAL AND CONSUMER INFORMATION

TECHNICAL INFORMATION


Serial Number Locations

Record the product identification number and engine serial number in the space provided on this page. You will need these numbers when ordering parts, and when making technical or warranty inquiries (p. 113).



The product identification number is stamped on a plate attached on top of the swivel case.

Product identification number:



ENGINE SERIAL NUMBER

The engine serial number is stamped on the cylinder block under the starter motor which is located in the front of the engine.

Engine serial number:

TECHNICAL AND CONSUMER INFORMATION

Carburetor Modification for High Altitude Operation

At high altitude, the standard carburetor air-fuel mixture will be too rich. Performance will decrease, and fuel consumption will increase. A very rich mixture will also foul the spark plugs and cause hard starting.

High altitude performance can be improved by specific modifications to the carburetors. If you always operate your outboard motor at altitudes above 5,000 feet (1,500 meters), have an authorized Honda marine dealer perform this carburetor modification.

Even with carburetor modification, engine horsepower will decrease about 3.5% for each 1,000-foot (300-meter) increase in altitude. The effect of altitude on horsepower will be greater than this if no carburetor modification is made.

NOTICE

When the carburetors have been modified for high altitude operation, the air-fuel mixture will be too lean for low altitude use. Operation at altitudes below 5,000 feet (1,500 meters) with modified carburetors may cause the engine to overheat and result in serious engine damage. For use at low altitudes, have an authorized Honda Marine dealer return the carburetors to original factory specifications.

Battery

For complete information, refer to the battery manufacturer's instructions.

Minimum Requirements

12V-65Ah (CCA 420)

TECHNICAL AND CONSUMER INFORMATION

Oxygenated Fuels

Some conventional gasolines are being blended with alcohol or an ether compound. These gasolines are collectively referred to as oxygenated fuels. To meet clean air standards, some areas of the United States and Canada use oxygenated fuels to help reduce emissions.

If you use an oxygenated fuel, be sure it is unleaded and meets the minimum octane rating requirement.

Before using an oxygenated fuel, try to confirm the fuel's contents. Some states/provinces require this information to be posted on the pump.

The following are the EPA-approved percentages of oxygenates:

ETHANOL: ethyl or grain alcohol; 10% by volume.

You may use gasoline containing up to 10% ethanol by volume. Gasoline containing ethanol may be marketed under the name "Gasohol".

MTBE: Methyl Tertiary Butyl Ether; 15% by volume.

You may use gasoline containing up to 15% MTBE by volume.

METHANOL: methyl or wood alcohol; 5% by volume.

You may use gasoline containing up to 5% methanol by volume, as long as it also contains cosolvents and corrosion inhibitors to protect the fuel system. Gasoline containing more than 5% methanol by volume may cause starting and/or performance problems. It may also

damage metal, rubber, and plastic parts of your fuel system.

If you notice any undesirable operating symptoms, try another service station, or switch to another brand of gasoline.

Fuel system damage or performance problems resulting from the use of an oxygenated fuel containing more than the percentages of oxygenates mentioned above are not covered under warranty.

Emission Control System Information

Source of Emissions

The combustion process produces carbon monoxide, oxides of nitrogen, and hydrocarbons. Control of hydrocarbons and oxides of nitrogen is very important because, under certain conditions, they react to form photochemical smog when subjected to sunlight. Carbon monoxide does not react in the same way, but it is toxic.

Honda utilizes lean carburetor settings and other systems to reduce the emissions of carbon monoxide, oxides of nitrogen, and hydrocarbons.

The U.S. and California Clean Air Acts

EPA and California regulations require all manufacturers to furnish written instructions describing the operation and maintenance of emission control systems.

The following instructions and procedures must be followed in order to keep the emissions from your Honda engine within the emission standards.

Tampering and Altering

Tampering with or altering the emission control system may increase emissions beyond the legal limit. Among those acts that constitute tampering are:

- Removal or alteration of any part of the intake, fuel, or exhaust systems.
- Alterations that would cause the engine to operate outside its design parameters.

TECHNICAL AND CONSUMER INFORMATION

Problems That May Affect Emissions

If you are aware of any of the following symptoms, have your engine inspected and repaired by your servicing dealer.

- Hard starting or stalling after starting.
- Rough idle.
- Misfiring or backfiring under load.
- Afterburning (backfiring).
- Black exhaust smoke or high fuel consumption.

Replacement Parts

The emission control systems on your Honda engine were designed, built, and certified to conform with EPA and California emission regulations. We recommend the use of genuine Honda parts whenever you have maintenance done. These original-design replacement parts are manufactured to the same standards as the original parts, so you can be confident of their performance. The use of replacement parts that are not of the original design and quality may impair the effectiveness of your emission control system.

A manufacturer of an aftermarket part assumes the responsibility that the part will not adversely affect emission performance. The manufacturer or rebuilder of the part must certify that use of the part will not result in a failure of the engine to comply with emission regulations.

Maintenance

Follow the maintenance schedule on p. 67. Remember that this schedule is based on the assumption that your machine will be used for its designed purpose. Sustained high-load operation, or use in unusual conditions, will require more frequent service.


TECHNICAL AND CONSUMER INFORMATION

Star Label

A Star label was applied to this outboard motor in accordance with the requirements of the California Air Resources Board.

The Star Label means Cleaner Marine Engine

This engine has been certified as a:



The Symbol for Cleaner Marine Engines:

Cleaner Air and Water - for healthier lifestyle and environment.

Better Fuel Economy - burns up to 30 - 40 percent less gas and oil than conventional carbureted two-stroke engines, saving money and resources.

Longer Emission Warranty - protects consumer for worry free operation.

TECHNICAL AND CONSUMER INFORMATION



One Star Low Emission

The one-star label identifies engines that meet the Air Resources Board's Personal Watercraft and Outboard marine engine 2001 exhaust emission standards. Engines meeting these standards have 75% lower emissions than conventional carbureted two-stroke engines. These engines are equivalent to the U.S.EPA's 2006 standards for marine engines.



Two Stars Very Low Emission

The two-star label identifies engines that meet the Air Resources Board's Personal Watercraft and Outboard marine engine 2004 exhaust emission standards. Engines meeting these standards have 20% lower emissions than One Star-Low Emission engines.



Three Stars Ultra Low Emission

The three-star label identifies engines that meet the Air Resources Board's Personal Watercraft and Outboard marine engine 2008 exhaust emission standards or the Sterndrive and inboard marine engine 2003-2008 exhaust emission standards. Engines meeting these standards have 65% lower emissions than One Star-Low Emission engines.



Four Stars Super Ultra Low Emission

The four-star label identifies engines that meet the Air Resources Board's Sterndrive and Inboard marine engine 2009 exhaust emission standards. Personal Watercraft and Outboard marine engines may also comply with these standards. Engines meeting these standards have 90% lower emissions than One Star-Low Emission engines.

Cleaner Watercraft - Get the Facts
1-800-END-SMOG
www.arb.ca.gov

TECHNICAL AND CONSUMER INFORMATION

Specifications

MODEL	BF25D		
Description Code	BATJ		
Type	H	HG	HT
Overall length	28.3 in (720 mm)		
Overall width	14.8 in (375 mm)		
Overall height	S	47.0 in (1,195 mm)	
	L	52.0 in (1,320 mm)	
Transom height	S	17.0 in (431 mm)	
	L	21.7 in (552 mm)	
Weight	S	155.4 lbs (70.5 kg)	179.7 lbs (81.5 kg)
	L	159.8 lbs (72.5 kg)	188.5 lbs (85.5 kg)
Rated power	18.7 kW (25 HP)		
Full throttle range	5,000 – 6,000 rpm		
Engine type	4 stroke OHC in-line 3 cylinder		
Displacement	33.7 cu-in (552 cm ³)		
Starter system	Recoil starter	Electric starter	
Ignition system	Digital ICM (Ignition Control Module)		
Lubrication system	Trochoid pump pressure lubrication		
Specified oil	Engine: API standard (Fuel Efficient SG, SH, SJ) SAE 5W-30 Gear case: API standard (GL-4/5) SAE 90 outboard motor gear oil		

Oil capacity	Engine: 2.0 US qt (1.9 ℓ) Gear case: 0.29 US qt (0.27 ℓ)	
CARB star label	ULTRA LOW EMISSION	
D.C. output	12V – 4A	12V – 10A
Cooling system	Water cooling with thermostat	
Exhaust system	Thru-hub	
Spark plugs	DR7EA (NGK) X22ESR-U (DENSO)	
Fuel pump	Diaphragm type	
Fuel	Automotive unleaded gasoline (86 pump octane or higher)	
Tank capacity	6.6 US gal (25 ℓ)	
Gear change	Forward-Neutral-Reverse (dog type)	
Steering angle	40° right and left	
Transom angle	5 stages (4°, 8°, 12°, 16°, 20°)	4 stages (8°, 12°, 16°, 20°)
Tilt angle (transom angle at 12°)	3 stages (30°, 45°, 75°)	Stageless (–4° to 68°)

Tuneup

Spark plug gap	0.024 – 0.028 in (0.60 – 0.70 mm)	See page 75
Idle speed	950 ± 50 rpm	See shop manual
Valve clearance (cold)	Intake: 0.12 ± 0.02 mm Exhaust: 0.20 ± 0.02 mm	See shop manual
Other specifications	No other adjustment is needed	

Honda outboards are power rated in accordance with NMMA procedures and using the ICOMIA standard 28/23.

TECHNICAL AND CONSUMER INFORMATION

Specifications

MODEL		BF25D	
Description Code		BATJ	
Type		RG	RT
Overall length		25.2 in (640 mm)	
Overall width		14.8 in (375 mm)	
Overall height	S	47.0 in (1,195 mm)	
	L	52.0 in (1,320 mm)	
Transom height	S	17.0 in (431 mm)	
	L	21.7 in (552 mm)	
Weight	S	169.8 lbs (77.0 kg)	174.2 lbs (79.0 kg)
	L	174.2 lbs (79.0 kg)	178.6 lbs (81.0 kg)
Rated power		18.7 kW (25 HP)	
Full throttle range		5,000 – 6,000 rpm	
Engine type		4 stroke OHC in-line 3 cylinder	
Displacement		33.7 cu-in (552 cm ³)	
Starter system		Electric starter	
Ignition system		Digital ICM (Ignition Control Module)	
Lubrication system		Trochoid pump pressure lubrication	
Specified oil		Engine: API standard (Fuel Efficient SG, SH, SJ) SAE 5W-30 Gear case: API standard (GL-4/5) SAE 90 outboard motor gear oil	

Oil capacity	Engine: 2.0 US qt (1.9 ℓ) Gear case: 0.29 US qt (0.27 ℓ)
CARB star label	ULTRA LOW EMISSION
D.C. output	12V – 10A
Cooling system	Water cooling with thermostat
Exhaust system	Thru-hub
Spark plugs	DR7EA (NGK) X22ESR-U (DENSO)
Fuel pump	Diaphragm type
Fuel	Automotive unleaded gasoline (86 pump octane or higher)
Tank capacity	6.6 US gal (25 ℓ)
Gear change	Forward-Neutral-Reverse (dog type)
Steering angle	40° right and left
Transom angle	4 stages (8°, 12°, 16°, 20°)
Tilt angle (transom angle at 12°)	Stageless (– 4° to 68°)

Tuneup

Spark plug gap	0.024 – 0.028 in (0.60 – 0.70 mm)	See page 75
Idle speed	950 ± 50 rpm	See shop manual
Valve clearance (cold)	Intake: 0.12 ± 0.02 mm Exhaust: 0.20 ± 0.02 mm	See shop manual
Other specifications	No other adjustment is needed	

Honda outboards are power rated in accordance with NMMA procedures and using the ICOMIA standard 28/23.

TECHNICAL AND CONSUMER INFORMATION

Specifications

MODEL	BF30D		
Description Code	BAUJ		
Type	H	HG	HT
Overall length	28.3 in (720 mm)		
Overall width	14.8 in (375 mm)		
Overall height	S	47.0 in (1,195 mm)	
	L	52.0 in (1,320 mm)	
Transom height	S	17.0 in (431 mm)	
	L	21.7 in (552 mm)	
Weight	S	179.7 lbs (81.5 kg)	
	L	159.8 lbs (72.5 kg)	
		188.5 lbs (85.5 kg)	
Rated power	22.4 kW (30 HP)		
Full throttle range	5,000 – 6,000 rpm		
Engine type	4 stroke OHC in-line 3 cylinder		
Displacement	33.7 cu-in (552 cm ³)		
Starter system	Recoil starter	Electric starter	
Ignition system	Digital ICM (Ignition Control Module)		
Lubrication system	Trochoid pump pressure lubrication		
Specified oil	Engine: API standard (Fuel Efficient SG, SH, SJ) SAE 5W-30 Gear case: API standard (GL-4/5) SAE 90 outboard motor gear oil		

Oil capacity	Engine: 2.0 US qt (1.9 ℓ) Gear case: 0.29 US qt (0.27 ℓ)	
CARB star label	ULTRA LOW EMISSION	
D.C. output	12V – 4A	12V – 10A
Cooling system	Water cooling with thermostat	
Exhaust system	Thru-hub	
Spark plugs	DR7EA (NGK) X22ESR-U (DENSO)	
Fuel pump	Diaphragm type	
Fuel	Automotive unleaded gasoline (86 pump octane or higher)	
Tank capacity	6.6 US gal (25 ℓ)	
Gear change	Forward-Neutral-Reverse (dog type)	
Steering angle	40° right and left	
Transom angle	5 stages (4°, 8°, 12°, 16°, 20°)	4 stages (8°, 12°, 16°, 20°)
Tilt angle (transom angle at 12°)	3 stages (30°, 45°, 75°)	Stageless (–4° to 68°)

Tuneup

Spark plug gap	0.024 – 0.028 in (0.60 – 0.70 mm)	See page 75
Idle speed	950 ± 50 rpm	See shop manual
Valve clearance (cold)	Intake: 0.12 ± 0.02 mm Exhaust: 0.20 ± 0.02 mm	See shop manual
Other specifications	No other adjustment is needed	

Honda outboards are power rated in accordance with NMMA procedures and using the ICOMIA standard 28/23.

TECHNICAL AND CONSUMER INFORMATION

Specifications

MODEL		BF30D	
Description Code		BAUJ	
Type		RG	RT
Overall length		25.2 in (640 mm)	
Overall width		14.8 in (375 mm)	
Overall height	S	47.0 in (1,195 mm)	
	L	52.0 in (1,320 mm)	
Transom height	S	17.0 in (431 mm)	
	L	21.7 in (552 mm)	
Weight	S	174.2 lbs (79.0 kg)	
	L	174.2 lbs (79.0 kg)	178.6 lbs (81.0 kg)
Rated power		22.4 kW (30 HP)	
Full throttle range		5,000 – 6,000 rpm	
Engine type		4 stroke OHC in-line 3 cylinder	
Displacement		33.7 cu-in (552 cm ³)	
Starter system		Electric starter	
Ignition system		Digital ICM (Ignition Control Module)	
Lubrication system		Trochoid pump pressure lubrication	
Specified oil		Engine: API standard (Fuel Efficient SG, SH, SJ) SAE 5W-30 Gear case: API standard (GL-4/5) SAE 90 outboard motor gear oil	

Oil capacity	Engine: 2.0 US qt (1.9 ℓ) Gear case: 0.29 US qt (0.27 ℓ)
CARB star label	ULTRA LOW EMISSION
D.C. output	12V – 10A
Cooling system	Water cooling with thermostat
Exhaust system	Thru-hub
Spark plugs	DR7EA (NGK) X22ESR-U (DENSO)
Fuel pump	Diaphragm type
Fuel	Automotive unleaded gasoline (86 pump octane or higher)
Tank capacity	6.6 US gal (25 ℓ)
Gear change	Forward-Neutral-Reverse (dog type)
Steering angle	40° right and left
Transom angle	4 stages (8°, 12°, 16°, 20°)
Tilt angle (transom angle at 12°)	Stageless (– 4° to 68°)

Tuneup

Spark plug gap	0.024 – 0.028 in (0.60 – 0.70 mm)	See page 75
Idle speed	950 ± 50 rpm	See shop manual
Valve clearance (cold)	Intake: 0.12 ± 0.02 mm Exhaust: 0.20 ± 0.02 mm	See shop manual
Other specifications	No other adjustment is needed	

Honda outboards are power rated in accordance with NMMA procedures and using the ICOMIA standard 28/23.

TECHNICAL AND CONSUMER INFORMATION

CONSUMER INFORMATION

Honda Publications

These publications will give you additional information for maintaining and repairing your outboard motor. You may purchase them from your Honda marine dealer.

Shop Manual

This manual covers complete maintenance and overhaul procedures. It is intended to be used by a skilled technician.

Parts Catalog

This manual provides complete, illustrated parts lists.

Warranty Service Information

Honda Marine dealership personnel are trained professionals. They should be able to answer any question you may have. If you encounter a problem that your dealer does not solve to your satisfaction, please discuss it with the dealership's management. The Service Manager or General Manager can help. Almost all problems are solved in this way.

If you are dissatisfied with the decision made by the dealership's management, contact the Honda Marine Customer Relations Office. You can write:

American Honda Motor Co., Inc.
Marine Division
Customer Relations Office
4900 Marconi Drive
Alpharetta, Georgia 30005-8847

Or telephone: (770) 497-6400

When you write or call, please give us this information:

- Model and serial numbers (p.102)
- Name of the dealer who sold the outboard motor to you
- Name and address of the dealer who services your outboard motor
- Date of purchase
- Your name, address, and telephone number
- A detailed description of the problem

INDEX

Anodes.....	29	EMERGENCY STARTING.....	48
Replacement.....	82	Emission Control System Information.....	107
ARE YOU READY TO GET UNDER WAY ?	37	Emergency Stop Switch and Switch Clip.....	17
ATTACHMENT	33	Engine	
Battery	105	Cover	
Connections.....	34	Latches	24
BATTERY WILL NOT CHARGE AND		REMOVAL AND INSTALLATION.....	70
ELECTRIC STARTER WILL NOT		Oil	
OPERATE.....	99	Change.....	72
BEFORE OPERATION.....	37	Level Check	71
BOAT TRANSOM REQUIREMENTS	32	Recommendations.....	73
BREAK-IN PROCEDURE.....	39	Fast Idle Lever (side-mount type).....	21
Carburetor Modification for High Altitude		Fuel	
Operation.....	105	Cap Vent Knob.....	30
Common Controls	23	HOSE CONNECTIONS	42
COMPONENT AND CONTROL LOCATIONS	11	Gauge.....	26
CONSUMER INFORMATION	115	PRIMING	43
CONTROLS.....	16	Priming Bulb	31
CONTROLS AND FEATURE IDENTIFICATION		RECOMMENDATIONS.....	78
CODES.....	10	Pump Filter Inspection and Replacement	79
CONTROLS AND FEATURES	10	Fuse Replacement	99
Cooling System Indicator.....	29		
CRUISING	56		

Gearshift Lever.....	18	MAINTENANCE SAFETY	65
Gearshift/Trottle Control Lever		MAINTENANCE SCHEDULE	67
SRG, LRG, SRT and LRT Types (remote control)		MANUAL RELIEF VALVE.....	24, 70
Side-Mount Type	22	MOORING, BEACHING, LAUNCHING.....	61
GEARSHIFTING AND THROTTLE OPERATION ...	53		
SH, LH, SHG and LHT Types (long tiller handle)....	53	Oil Pressue Indicator	27
SRG, LRG, SRT and LRT Types (remote control)...	54	OIL PRESSURE INDICATOR LIGHT GOES	
		OFF AND ENGINE SPEED IS LIMITED	100
Honda Publications	115	OPERATION	39
		OTHER FEATURES	29
Ignition Switch		OUTBOARD MOTOR SAFETY.....	7
SHG and LHT Types (long tiller handle)	16	Overheating Indicator.....	28
SRG, LRG, SRT and LRT Types (remote control)		OVERHEATING INDICATOR LIGHT COMES	
Side-Mount Type	20	ON AND ENGINE SPEED IS LIMITED	101
IMPORTANT SAFETY INFORMATION	7	Overrev Limiter.....	29
INDEX.....	116	Oxygenated Fuels.....	106
INDICATORS.....	27		
INSTALLATION.....	32	PORTABLE FUEL TANK.....	30, 42
POSITION.....	32	Portable Fuel Tank and Filter Cleaning	81
INSTRUMENTS.....	26	Power Tilt Switch.....	23
IS YOUR OUTBOARD MOTOR		Power Trim/Tilt Switch	23
READY TO GO ?	37	Propeller Replacement	83
Lubrication Points	74		

INDEX


Recoil Starter Grip (SH and LH types).....	16	STORAGE	84
REFUELING.....	77	STORAGE PRECAUTIONS.....	89
REMOVAL FROM STORAGE.....	90	STORAGE PREPARATION.....	84
SAFE OPERATING PRECAUTIONS	39	Cleaning and Flushing	84
SAFETY LABEL LOCATIONS.....	9	Engine oil	89
Serial Number Locations.....	104	Fuel.....	87
SERVICING YOUR OUTBOARD MOTOR.....	64	SUBMERGED MOTOR	102
SHALLOW WATER OPERATIONS.....	58	Switch Clip and Emergency Stop Switch	
Spark Plug Service	75	SRG, LRG, SRT and LRT Types (remote control)	
Specifications	111	Side-Mount Type	20
Star Label	109	Tachometer (optional equipment).....	26
STARTING THE ENGINE		TAKING CARE OF UNEXPECTED PROBLEMS.....	92
SH, LH, SHG and LHT Types (long tiller handle)....	43	TECHNICAL AND CONSUMER INFORMATION.	104
SRG, LRG, SRT and LRT Types (remote control)...	46	TECHNICAL INFORMATION.....	104
STEERING.....	55	THE IMPORTANCE OF MAINTENANCE	64
SH, LH, SHG and LHT Types (long tiller handle)....	55	Throttle Friction Adjuster	18
SRG, LRG, SRT and LRT Types (remote control)...	55	Throttle Grip.....	17
Steering Friction Adjuster	18, 55	Tilt Lever	
STOPPING THE ENGINE.....	51	(mechanical tilt/SH and LH types)	19
Emergency Engine Stopping.....	51	(gas-assisted tilt/SHG, SRG and LRG types)	19
Normal Engine Stopping.....	51	Tilt Lock Lever	
		(SHG, LHT, SRG, LRG, SRT and LRT types).....	24
		TOOL KIT AND EMERGENCY STARTER ROPE ...	66
		TRANSOM ANGLE ADJUSTMENT	34, 40
		Transom Angle Adjusting Rod	25

TRANSPORTING 91
 WITH OUTBOARD MOTOR INSTALLED
 ON BOAT 91
 WITH OUTBOARD MOTOR REMOVED
 FROM BOAT 92
Trim Meter (optional equipment) 26
Trim Tab..... 25, 58
TRIM TAB ADJUSTMENT 69

Warranty Service Information 115
WIRING DIAGRAMS..... Inside Back Cover




WIRING DIAGRAM

LONG TILLER HANDLE, MECHANICAL TILT TYPE
(with recoil starter and 4A charge coil type)



WIRING DIAGRAM

LONG TILLER HANDLE, GAS-ASSISTED TILT TYPE




BI	BLACK	Br	BROWN
Y	YELLOW	O	ORANGE
Bu	BLUE	Lb	LIGHT BLUE
G	GREEN	Lg	LIGHT GREEN
R	RED	P	PINK
W	WHITE	Gr	GRAY

FUSE (10A)


WIRING DIAGRAM

LONG TILLER HANDLE, POWER TRIM/TILT TYPE





WIRING DIAGRAM

REMOTE CONTROL, GAS-ASSISTED TILT TYPE



EMERGENCY STOP SWITCH




FUSE (10A)

BI	BLACK	Br	BROWN
Y	YELLOW	O	ORANGE
Bu	BLUE	Lb	LIGHT BLUE
G	GREEN	Lg	LIGHT GREEN
R	RED	P	PINK
W	WHITE	Gr	GRAY


WIRING DIAGRAM

REMOTE CONTROL, POWER TRIM/TILT TYPE



HONDA

The power of dreams.™



31ZW2600
00X31-ZW2-6000



500.2003.07

Printed in Japan