


BF15A Owner's Manual



2002

▲ WARNING:

The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

Keep this owner's manual handy, so you can refer to it at any time. This owner's manual is considered a permanent part of the outboard motor and should remain with the outboard motor if resold.

The information and specifications included in this publication were in effect at the time of approval for printing. Honda Motor Co., Ltd. reserves the right, however, to discontinue or change specifications or design at any time without notice and without incurring any obligation whatever. No part of this publication may be reproduced without written permission.

INTRODUCTION

Congratulations on your selection of a Honda outboard motor. We are certain you will be pleased with your purchase of one of the finest outboard motors on the market.

We want to help you get the best results from your new outboard motor and to operate it safely. This manual contains the information on how to do that; please read it carefully.

As you read this manual you will find information preceded by a

NOTICE symbol. That information is intended to help you avoid damage to your outboard motor, other property, or the environment.

We suggest you read the warranty policy to fully understand its coverage and your responsibilities of ownership. The warranty policy is a separate document that should have been given to you by your dealer.

When your outboard motor needs scheduled maintenance, keep in mind that your Honda marine dealer is specially trained in servicing Honda outboard motors. Your Honda marine dealer is dedicated to your satisfaction and will be pleased to answer your questions and concerns.

© 2001 Honda Motor Co., Ltd. All Rights Reserved

INTRODUCTION

A FEW WORDS ABOUT SAFETY

Your safety and the safety of others are very important. And using this outboard motor safely is an important responsibility.

To help you make informed decisions about safety, we have provided operating procedures and other information on labels and in this manual. This information alerts you to potential hazards that could hurt you or others.

Of course, it is not practical or possible to warn you about all the hazards associated with operating or maintaining an outboard motor. You must use your own good judgment. You will find important safety information in a variety of forms, including:

- Safety Labels on the outboard motor.
- Safety Messages preceded by a safety alert symbol **A** and one of three signal words, DANGER, WARNING, or CAUTION.

These signal words mean:

A DANGER

You WILL be KILLED or SERIOUSLY HURT if you don't follow instructions.

A WARNING

You CAN be KILLED or SERIOUSLY HURT if you don't follow instructions.

A CAUTION

You CAN be HURT if you don't follow instructions

- Safety Headings such as IMPORTANT SAFETY INFORMATION.
- Safety Section such as OUTBOARD MOTOR SAFETY.
- **Instructions** how to use this outboard motor correctly and safely.

This entire book is filled with important safety information — please read it carefully.

OUTBOARD MOTOR SAFETY7
IMPORTANT SAFETY INFORMATION7
SAFETY LABEL LOCATIONS9
CONTROLS AND FEATURES10
CONTROLS AND FEATURE
IDENTIFICATION CODES10
COMPONENT AND CONTROL LOCATIONS 11
CONTROLS
Engine Stop Switch and Switch Clip
Choke Knob 13
Throttle Grip14
Throttle Friction Knob 14
Gearshift Lever14
Recoil Starter Grip
Electric Starter Button (models equipped
with electric starter)
COMMON CONTROLS 15
Engine Cover Lock Levers
Transom Angle Adjusting Rod 16
Steering Friction Bolt
Tilt Lever

INSTRUMENTS	., 17
Fuel Gauge	17
INDICATORS	
Oil Pressure Indicator	17
Cooling System Indicator	18
OTHER FEÁTURES	
Overrev Limiter	
Anode	18
Portable Fuel Tank	19
Fuel Cap Vent Knob	19
Fuel Priming Bulb	

20
20
20
20
21
22
22
25
25
25

OPERATION	27
SAFE OPERATING PRECAUTIONS	27
BREAK-IN PROCEDURE	
TRANSOM ANGLE ADJUSTMENT	27
PORTABLE FUEL TANK	28
FUEL HOSE CONNECTIONS	28
FUEL PRIMING	29
STARTING THE ENGINE	29
EMERGENCY STARTING	32
STOPPING THE ENGINE	34
Emergency Engine Stopping	34
Normal Engine Stopping	
GEARSHIFTING AND	
THROTTLE OPERATION	3 <i>6</i>
STEERING	
CRUISING	
SHALLOW WATER OPERATIONS	39
MOORING, BEACHING, LAUNCHING	40

SERVICING YOUR OUTBOARD MOTOR41	
THE IMPORTANCE OF MAINTENANCE 41	
MAINTENANCE SAFETY 42	
TOLL KIT AND EMERGENCY STARTER	
ROPE43	
MAINTENANCE SCHEDULE 44	
ENGINE COVER REMOVAL AND	
INSTALLATION 46	
Engine Oil Level Check	
Engine Oil Change	
Engine Oil Recommendations	
Gear Oil Level Check	
Gear Oil Change	
Lubrication Points	
Spark Plug Service	
REFUELING54	
FUEL RECOMMENDATIONS55	
Fuel Pump Filter Inspection and Replacement 55	
Portable Fuel Tank and Filter Cleaning 57	
Fuel Tank Filter57	
Recoil Starter Rope Inspection	
Anode Replacement 58	
Propeller Replacement	

STORAGE	60
STORAGE PREPARATION	60
Cleaning and Flushing	
Fuel	62
Engine Oil	64
STORAGE PRECAUTIONS	64
REMOVAL FROM STORAGE	65
TRANSPORTING	66
WITH OUTBOARD MOTOR INSTALLED	
ON BOAT	66
WITH OUTBOARD MOTOR REMOVED	
FROM BOAT	66

TAKING CARE OF UNEXPECTED	
PROBLEMS67	
ELECTRICAL STARTER WILL NOT	
OPERATE 67	
ENGINE WILL NOT START 68	
HARD STARTING OR STALLS	
AFTER STARTING70	
ENGINE OVERHEATS71	
BATTERY WILL NOT CHARGE AND	
ELECTRIC STARTER WILL NOT OPERATE 72	
OIL PRESSURE INDICATOR LIGHT GOES	
OFF AND ENGINE SPEED IS LIMITED 73	
SUBMERGED MOTOR74	
ΓΕCHNICAL AND CONSUMER INFORMATION 76	
TECHNICAL INFORMATION	
TECHNICAL INFORMATION 76 Serial Number Locations 76 Carburetor Modification for High Altitude Operation 77 Oxygenated Fuels 78 Emission Control System Information 79	
TECHNICAL INFORMATION 76 Serial Number Locations 76 Carburetor Modification for High Altitude 77 Operation 78 Emission Control System Information 79 Star Label 81 Specifications 83	
TECHNICAL INFORMATION 76 Serial Number Locations 76 Carburetor Modification for High Altitude Operation 77 Oxygenated Fuels 78 Emission Control System Information 79	

WIRING DIAGRAMS	86
INDEX	88

OUTBOARD MOTOR SAFETY

IMPORTANT SAFETY INFORMATION

The Honda BF15A outboard motor is designed for use with boats that have a suitable manufacturer's power recommendation. Other uses can result in injury to the operator or damage to the outboard motor and other property.

Most accidents can be prevented if you follow all instructions in this manual and on the outboard motor. The most common hazards are discussed below, along with the best way to protect yourself and others.

Operator Responsibility

- It is the operator's responsibility to provide the necessary safeguards to protect people and property.
 Know how to stop the engine quickly in case of emergency.
 Understand the use of all controls.
- Stop the engine immediately if anyone falls overboard, and do not run the engine while the boat is near anyone in the water.
- Always stop the engine if you must leave the controls for any reason.

- Attach the emergency stop switch lanyard securely to the operator.
- Always wear a PFD (Personal Flotation Device) while on the boat.
- Familiarize yourself with all laws and regulations relating to boating and the use of outboard motors.
- Be sure that anyone who operates the outboard motor receives proper instruction.
- Be sure the outboard motor is properly mounted on the boat.
- Do not remove the engine cover while the engine is running.

OUTBOARD MOTOR SAFETY


Refuel With Care

- Gasoline is extremely flammable, and gasoline vapor can explode. Refuel outdoors, in a wellventilated area, with the engine stopped. Never smoke near gasoline, and keep other flames and sparks away.
- Remove any portable fuel tank from the boat for refueling. Keep the portable fuel tank away from the battery or other potential spark sources.
- Refuel carefully to avoid spilling fuel. Avoid overfilling the fuel tank
- After refueling, tighten the filler cap securely. If any fuel is spilled, make sure the area is dry before starting the engine.

Carbon Monoxide Hazard

Exhaust gas contains poisonous carbon monoxide. Avoid inhalation of exhaust gas. Never run the engine in a closed garage or confined area.

SAFETY LABEL LOCATIONS



The labels shown here contain important safety information. Please read them carefully. These labels are considered permanent parts of your outboard motor. If a label comes off or becomes hard to read, contact an authorized Honda Marine servicing dealer for a replacement.

CONTROLS AND FEATURES


CONTROL AND FEATURE IDENTIFICATION CODES

Model	BF15A				
Туре	SA	LA	SAS	LAS	XAS
Shaft Length	s	L	S	L	X
Electric Starter			S	S	S
Battery Charging DC Receptacle	•	•			


Refer to this chart for an explanation of the Type Codes used in this manual to identify control and feature applications,


BF15A is provided with the following types according to the shaft length, and start system.

According to Shaft Length
 S: Short Shaft
 L: Long Shaft
 X: Extra Long Shaft




COMPONENT AND CONTROL LOCATIONS






CONTROLS

Engine Stop Switch and Switch Clip






The engine stop switch has controls for normal engine stopping and emergency engine stopping.

The switch clip must be inserted in the engine stop switch in order for the engine to start and run. The lanyard should be attached to the operator's PFD (Personal Flotation Device) or worn around the wrist as shown.

When used as described, the engine stop switch and lanyard system stops the engine if the operator falls away from the controls.

A spare switch clip is supplied with the tool kit.

Choke Knob




The choke knob opens and closes the choke valves in the carburetors.

The CLOSED position enriches the fuel mixture for starting a cold engine.

The OPEN position provides the correct fuel mixture for operation after starting, and for restarting a warm engine.


CONTROLS AND FEATURES



The throttle grip controls engine speed.

An index mark on the tiller arm shows throttle position and is helpful for setting the throttle correctly when starting (p. 30).

Throttle Friction Knob




The throttle friction knob adjusts resistance to throttle grip rotation.

Turn the knob clockwise to increase friction for holding a throttle setting while cruising.

Turn the knob counterclockwise to decrease friction for easy throttle grip rotation.

Gearshift Lever




The gearshift lever is used to select F (forward), N (neutral), or R (reverse) gears.

The engine can be started with the gearshift lever in the N (neutral) position only.

If the gearshift lever is in the F (forward) or R (reverse) position, the recoil starter will not operate, and the electric starter button (applicable models) will not operate the starter motor.

Recoil Starter Grip




Pull the starter grip to operate the recoil starter for starting the engine manually.

The recoil starter will operate only when the gearshift lever (p. 14) is in the N (neutral) position, and the clip is in the engine stop switch or the emergency stop switch.

Electric Starter Button (models equipped with electric starter)

ELECTRIC STARTER BUTTON




Press the starter button to operate the electric starter for starting the engine.

The electric starter button can be used to operate the starter motor only when the gearshift lever (p. 14) is in the N (neutral) position, and the clip is in the engine stop switch.

Common Controls

Engine Cover Lock Lever

ENGINE COVER LOCK LEVER




The engine cover lock lever fastens the engine cover to the outboard motor.

CONTROLS AND FEATURES


Transom Angle Adjusting Rod

The transom angle adjusting rod limits the tilt angle of the outboard motor when fully lowered.



Proper adjustment prevents the outboard motor from being trimmed too low (p. 38).


Steering Friction Bolt



The steering friction bolt adjusts steering resistance.

Less friction allows the outboard motor to turn more easily. More friction helps to hold steady course while cruising or to prevent the outboard motor from swinging while trailering the boat.

Tilt Lever




The tilt lever enables the outboard motor to be raised for shallow water operation, beaching, launching, or mooring.

To tilt, move the lever to the TILT position, then raise the outboard motor until the tilt mechanism engages at 30°, 45°, or 70° (p. 39).

INSTRUMENTS


Fuel Gauge



A fuel gauge is built into the cap of the portable fuel tank.

INDICATORS

Oil Pressure Indicator




When the green light is lit, oil pressure is OK.

If oil pressure becomes low, the green light will go off, and the engine protection system will limit engine speed.

Low oil pressure indicates that the engine oil level is low, or that there is a problem with the engine lubrication system.

Cooling System Indicator



COOLING SYSTEM INDICATOR

Water should flow from the cooling system indicator while the engine is running. This shows that water is circulating through the cooling system.

If water stops flowing while the engine is running, that indicates a cooling system problem, such as clogged water intakes, which will cause engine overheating.

OTHER FEATURES


Overrey Limiter

The engine is equipped with an overrev limiter to prevent the possibility of mechanical damage from excessive engine speed.

The overrev limiter may be activated during operation, limiting engine speed, if the outboard motor is tilted excessively, or when ventilation occurs during a sharp turn.

If the overrev limiter is activated, check the trim angle of the outboard motor.


Anode



The anode is made of a sacrificial material that helps to protect the outboard motor from corrosion.


There is an anode on the antiventilation plate.

Portable Fuel Tank




The portable fuel tank has a capacity of 3.2 US gal ($12 \, l$) and has a fuel gauge built into the cap.

Fuel Cap Vent Knob



The cap is provided with a vent knob to seal the portable fuel tank for carrying it to and from the boat. Open the vent knob 2 or 3 turns before starting the engine (p. 28).

Fuel Priming Bulb



A priming bulb is built into the fuel hose that connects the fuel tank to the outboard motor.

Before starting the engine, squeeze the priming bulb until it feels firm. This will ensure that fuel is supplied to the engine (p. 29).

INSTALLATION

Correct and secure installation is essential for safe boating and good performance. Follow the installation instructions provided in this manual.


POWER REQUIREMENTS

Before installation, check to be sure that the outboard motor does not exceed the recommended maximum horsepower for the boat on which it is to be installed. Refer to the boat's certification plate for recommended maximum horsepower. If the certification plate information is not available, contact the boat dealer or manufacturer.


For most applications, the outboard motor should have a horsepower rating which provides 80% of the maximum recommended horsepower for the boat.

BOAT TRANSOM REQUIREMENTS

INSTALLATION POSITION




Install the outboard motor on the center of the boat transom.



Type:	Motor Transom Height
S:	17.3 in (440 mm)
L:	22.4 in (570 mm)
X:	28.0 in (710 mm)

The antiventilation plate of the outboard motor should be 0-2.0 inches below the bottom of the boat. With the boat in the water and loaded, the antiventilation plate should be about 3.9 inches below the surface of the water.




If the outboard motor is installed too low, the boat will squat and be hard to plane, it will tend to porpoise, and high-speed stability will be reduced.

If the outboard motor is installed too high, that will cause ventilation.

Optimum installation height varies with boat type and bottom shape. Contact the boat manufacturer for any special recommendations that are unique to a specific model of boat.

If the transom needs to be modified to accommodate the outboard motor, contact the boat manufacturer and follow their recommendations for corrective action.



Attach the stern bracket to the boat transom by tightening the clamp screws.

Attach a rope from the boat to the hole in the stern bracket. This will help to prevent accidental loss of the outboard motor.


You may further secure the outboard motor by bolting the stern bracket to the boat transom. Use the optional mounting bolt and nut kit or other good quality stainless steel bolts, nuts, and washers. Apply silicone sealant to the bolt holes.

INSTALLATION

TRANSOM ANGLE ADJUSTMENT

Use the transom angle adjustment rod (p. 27) to adjust the angle of the outboard motor so the propeller is perpendicular to the surface of the water.

BATTERY CONNECTIONS



The Honda BF15A outboard motor produce a 12-volt, 6-ampere battery-charging current and are equipped for connection to a 12-volt battery. The battery-charging circuit is protected by a 15-ampere fuse located in the engine compartment.

The outboard motor's 12-volt output is intended for battery charging only. Lights and electrical accessories for the boat should be connected to the battery.

The battery should be kept in a corrosion-resistant battery box that is securely mounted in a location away from the fuel tank and protected from water and direct sunlight.

Types With Electric Starter


These types are equipped with battery cables. The positive (+) cable has a red band at the battery connector. The negative (-) cable has a black band at the battery connector.

For electric starter operation, use a 12-volt battery with an ampere-hour rating of at least 40 Ah.

Types Without Electric Starter

These types are equipped with a 12-volt dc battery-charging receptacle which can be wired to a 12-volt battery to power lights and electrical accessories for the boat.

Plug and Receptacle (models without electric starter)



To prepare the outboard motor for connection to a battery, pull the plug out of its rubber boot, route suitable electrical wires through the boot, and screw them to the plug positive (+) and negative (-) terminals. Coat the plug terminals with anticorrosion grease, and reinstall the plug in the rubber boot.


The receptacle is provided with a rubber cap, which should be attached when the plug is removed, in order to keep the receptacle clean and dry.

Battery

Minimum Requirements

12V-40AH

Battery Terminals



Connect the positive (+) battery cable to the positive (+) battery terminal, then connect the negative (-) battery cable to the negative (-) battery terminal.

The negative (-) battery cable should always be removed from the battery when connecting or disconnecting the positive (+) battery cable, so tools cannot cause a short circuit if they touch a grounded part while being used on the positive (+) battery terminal fitting.

INSTALLATION

NOTICE

Be careful to avoid connecting the battery in reverse polarity, as that will damage the battery-charging system in the outboard motor.

BEFORE OPERATION

ARE YOU READY TO GET UNDER WAY?

Your safety is your responsibility. A little time spent in preparation will significantly reduce your risk of injury.

Knowledge

Read and understand this manual. Know what the controls do and how to operate them.

Familiarize yourself with the outboard motor and its operation before you get under way. Know what to do in case of emergencies.

Familiarize yourself with all laws and regulations relating to boating and the use of outboard motors.

Safety

Always wear a PFD (Personal Flotation Device) while on the boat.

Attach the emergency stop switch lanyard securely to your PFD or to your wrist.

IS YOUR OUTBOARD MOTOR READY TO GO?

For your safety, and to maximize the service life of your equipment, it is very important to take a few moments before you operate the outboard motor to check its condition. Be sure to take care of any problem you find, or have your authorized Honda Marine dealer correct it, before you operate the outboard motor.

AWARNING

Improperly maintaining this outboard motor, or failing to correct a problem before operation, could cause a malfunction in which you could be seriously injured.

Always perform a preoperation inspection before each operation, and correct any problem.

Before beginning your preoperation checks, be sure the ignition switch is in the OFF position.

BEFORE OPERATION

Safety Inspection

- Look around the outboard motor for signs of oil or gasoline leaks.
- If you are using the portable fuel tank, make sure it is in good condition and properly secured in the boat (p. 28).
- Check that the fuel hose is undamaged and properly connected (p. 28).
- Wipe up any spills before starting the engine.
- Check the stern bracket to be sure the outboard motor is securely installed.
- Check that all controls are operating properly.
- Replace any damaged parts.
- Check that all fasteners are in place and securely tightened.

Maintenance Inspection

- Check the engine oil level (p. 46).
 Running the engine with a low oil level can cause engine damage.
- Check to be sure the propeller is undamaged, and the castle nut is secured with the cotter pin (p. 59).
- Check that the anode is securely attached to the gear case (p. 58) and are not excessively worn. The anode helps to protect the outboard motor from corrosion.
- Make sure the tool kit and emergency starter rope are onboard (p. 43). Replace any missing items.
- Check the fuel level in the fuel tank (p. 54).

OPERATION

SAFE OPERATING PRECAUTIONS

To safely realize the full potential of this outboard motor, you need a complete understanding of its operation and a certain amount of practice with its controls.

Before operating the outboard motor for the first time, please review the *IMPORTANT SAFETY INFORMATION* on page 7 and the chapter titled *BEFORE OPERATION*.


For your safety, avoid starting or operating the engine in an enclosed area. Your engine's exhaust contains poisonous carbon monoxide gas which can collect rapidly in an enclosed area and cause illness or death.

BREAK-IN PROCEDURE

Proper break-in procedure allows the moving parts to wear in smoothly for best performance and long service life.

For the first 10 hours, run the outboard motor at low speed, and avoid full-throttle operation.

TRANSOM ANGLE ADJUSTMENT



The transom angle adjusting rod is used to adjust the angle of the outboard motor in the normal operating position (p. 38).

To adjust, first tilt the outboard motor so it is not resting on the rod.

Push the rod in and turn the end of the rod up, so the latch will fall into line with the rod.

Remove the rod and reinsert it in the desired position.

Push the rod in and turn the end of the rod down, so the latch will fall to the locked position. Then release the rod.

PORTABLE FUEL TANK



Place the portable fuel tank in a well-ventilated location, away from direct sunlight, to reduce the possibility of a gasoline vapor explosion.

To ensure that the outboard motor will be able to draw fuel from the tank, place the tank within 6 feet of the outboard motor and not more than 3 feet below the fuel connector on the outboard motor.

Secure the portable fuel tank in the boat, so it won't move around and become damaged.

Before use, open the fuel tank vent by turning the vent knob at least 2 or 3 turns counterclockwise.

AWARNING

Gasoline is highly flammable and explosive.


You can be burned or seriously injured when handling fuel.

- Stop the engine and keep heat, sparks, and flame away.
- Handle fuel only outdoors.
- Wipe up spills immediately.

FUEL HOSE CONNECTIONS

FUEL HOSE CONNECTOR






(OUTBOARD MOTOR SIDE)

Connect the fuel hose to the tank and the outboard motor, as shown. Be sure both connectors snap securely into place.

FUEL PRIMING




Hold the priming bulb up in the direction of the arrow, then squeeze the priming bulb several times until it feels firm, indicating that fuel has reached the engine.

Check to be sure there are no fuel leaks before starting the engine.

Do not squeeze the priming bulb when the engine is running because that could flood the carburetors.

STARTING THE ENGINE




1. Put the emergency stop switch clip in the engine stop switch, and attach the lanyard to your PFD (Personal Flotation Device) or to your wrist, as shown. The engine will not start or run, unless the clip is in the switch.

The emergency stop switch clip and lanyard system is a safety device that will stop the engine if you fall away from the controls while operating the boat.


Always attach the lanyard to your PFD, or to your wrist, before starting the engine.

OPERATION




2. Check the position of the gearshift lever. It must be in the N (neutral) position for starting.


The engine will not start if the gearshift lever is in the F (forward) or R (reverse) position.




3. To start a cold engine, pull the choke knob to the CLOSED position. To restart a warm engine, leave the choke knob in the OPEN position.



4. Align the START position with the pointer for starting the engine.



ELECTRIC STARTER BUTTON



5. Recoil starter
Pull the recoil starter grip slowly
until you feel resistance, then pull
briskly.

Return the starter grip gently.

Electric starter (electric starter model)
Press the electric starter button and hold it there until the engine starts.

When the engine starts, release the button.

If the engine fails to start within 5 seconds, release the button, and wait at least 10 seconds before operating the starter again.

NOTICE

- Using the electric starter for more than 5 seconds at a time will overheat the starter motor and can damage it.
- Pushing the electric starter button while the engine is running can damage the starter motor and flywheel.

 If the choke knob was pulled to the CLOSED position to start the engine, gradually push it to the OPEN position as the engine warms up.

Also, as the engine warms up, the throttle grip can be turned to the SLOW position without stalling.

7. Before getting under way, allow the engine to warm up sufficiently to ensure good performance.

During the warm-up period, check the oil pressure indicator (p. 17) and cooling system indicator (p. 18).


If the indicators show any abnormal condition, immediately stop the engine and determine the cause of the problem. Refer to TAKING CARE OF UNEXPECTED PROBLEMS, p. 78.

OPERATION


EMERGENCY STARTING

If the battery is discharged, or the starter motor and the recoil starter are inoperative, you can start the engine manually using the emergency starter rope supplied with the tool kit.

ENGINE COVER LOCK LEVER




1. Unlock and remove the engine cover.




- Move the shift lever to the F
 (forward) position. Loosen the
 neutral start cable lock nut and
 disconnect the neutral start cable.
 Unscrew the three bolts and
 remove the recoil starter assembly.
- Set the controls the same as for normal starting (see pages 29 – 31). Use the choke control if needed.

Turn the ignition switch key to the ON position.



4. Set the knotted end of the emergency starter rope in the notch in the flywheel. Wind the rope clockwise around the flywheel, as shown.



5. Pull the emergency starter rope slowly until resistance is felt, then pull briskly.

Keep away from moving parts while pulling the rope.

If necessary, rewind the rope and pull again. If the engine does not start after several attempts, refer to TAKING CARE OF UNEXPECTED PROBLEMS, p. 67.

6. If the choke control was used to start the engine, return the control to the normal operating position as the engine warms up.

During the warm-up period, check the oil pressure indicator (p. 17), and cooling system indicator (p. 18).

7. Leave the recoil starter assembly off, but install the engine cover (p. 15), and lock it in place by locking the engine cover lock lever.

AWARNING

Exposed moving parts can cause injury.

- Do not operate the outboard motor without the engine cover.
- Use extreme care when installing the engine cover.


OPERATION

- 8. If it was necessary to remove the emergency stop switch lanyard from your wrist to perform the emergency starting procedure, be sure the lanyard is attached to your wrist before operating the outboard motor.
- Have your closest authorized Honda marine dealer check your electrical system and correct the problem, so you can use the electric starter.

The recoil starter assembly (p. 32) should be reinstalled after the electric starter is working again. Install the recoil starter assembly with the engine stopped.

STOPPING THE ENGINE


Emergency Engine Stopping




To stop the engine in an emergency, pull the clip out of the engine or emergency stop switch by pulling the lanyard.


We suggest that you stop the engine this way occasionally to verify that the engine stop switch is operating properly.

Normal Engine Stopping





1. Move the throttle grip to the slowest speed and control gears to N (neutral) position.




2. Press the engine stop switch until the engine stops.

3. When the boat is not in use, remove and store the emergency stop switch clip and lanyard.

OPERATION

GEARSHIFTING AND THROTTLE OPERATION






To shift gears, turn the throttle grip to the SLOW position, then move the gearshift lever to select F (forward), N (neutral) or R (reverse) gears.

The engine can be started with the gearshift lever in the N (neutral) position only.

The throttle grip can be turned to the FAST position only when the gearshift lever is in the F (forward) position.





Use the throttle friction knob to help hold a constant throttle setting while cruising.


Turn the knob clockwise to increase throttle grip friction for holding a constant speed.

Turn the knob counterclockwise to decrease friction for easy grip rotation.

STEERING







Use the steering friction bolt to help hold a steady course while cruising.

Turn the bolt clockwise to increase steering friction for holding a steady course.

Turn the bolt counterclockwise to decrease friction for easy turning.

CRUISING

Engine Speed

For best fuel economy, limit the throttle opening to 80%. Use the throttle friction control (p. 36) to help you hold a steady speed.

For rough water conditions or large waves, slow down to prevent the propeller from rising out of the water.

The engine is equipped with an overrev limiter to prevent the possibility of mechanical damage from excessive engine speed.

If, for example, the outboard motor is tilted excessively, or ventilation occurs during a sharp turn, the engine may overrev, activating the overrev limiter.

If engine speed becomes unstable at high speed due to activation of the overrev limiter, reduce speed and check the trim angle of the outboard motor.

Trim

Install the outboard motor at the best trim angle for stable cruising and maximum power.

Trim angle too large: Incorrect causes boat to "squat."

Trim angle too small: Incorrect causes boat to "plow."

It is necessary to trim the angle of the outboard motor to compensate for changes in boat load, weight distribution, water conditions, or propeller selection.


Under normal conditions, the boat will perform best when the antiventilation plate is level with the water.

When cruising into a high wind, trim the outboard motor down slightly to level the boat and improve stability. With a tail wind, trim the outboard motor up slightly.

NOTICE

Excessive trim/tilt angle during operation can cause propeller ventilation, overheating, and water pump damage.


Motor Angle (Cruising)




CORRECT GIVES MAXIMUM PERFORMANCE

SHALLOW WATER OPERATION

When operating in shallow water, tilt the outboard motor, using the tilt lever, so the propeller and gear case won't hit the bottom.





To tilt the outboard motor, move the tilt lever to the TILT position, then raise the outboard motor to the 30° or 45° position by pulling on the engine cover grip.

NOTICE

Do not use the tiller handle as a lever to raise the outboard motor. Applying excessive force to the tiller handle can damage it.


While the outboard motor is tilted, proceed at a low speed, and do not operate the outboard motor in reverse. The outboard motor will rise suddenly if operated in reverse.

Monitor water flow from the cooling system indicator (p. 18) to be sure the outboard motor is not tilted so high the water intake is out of the water.

OPERATION


NOTICE

An excessive tilt angle during operation can cause propeller ventilation, overheating, and water pump damage.



To return the outboard motor to the normal operating position, move the tilt lever to the RUN position, raise the outboard motor slightly to disengage the tilt mechanism, then slowly lower the outboard motor.

MOORING, BEACHING, LAUNCHING



To raise the outboard motor out of the water while the boat is moored, or for maximum clearance when beaching or launching, tilt the outboard motor to the 70° position.

Stop the engine before tilting the outboard motor. The 70° position is not an operating position.

Raise and lower the outboard motor as described on p. 39.

THE IMPORTANCE OF MAINTENANCE

Good maintenance is essential for safe, economical, and trouble-free operation. It will also help reduce air pollution.

AWARNING

Improperly maintaining this outboard motor, or failure to correct a problem before operation, can cause a malfunction in which you could be seriously hurt or killed.

Always follow the inspection and maintenance recommendations and schedules in this owner's manual.

To help you properly care for your outboard motor, the following pages include a maintenance schedule, routine inspection procedures, and simple maintenance procedures using basic hand tools. Other service tasks that are more difficult, or require special tools, are best handled by professionals and are normally performed by a Honda technician or other qualified mechanic.

The maintenance schedule applies to normal operating conditions. If you operate your outboard motor under unusual conditions, consult an authorized Honda marine dealer for recommendations applicable to your individual needs and use.

Remember that your authorized Honda marine dealer knows your outboard motor best and is fully equipped to maintain and repair it.

To ensure the best quality and reliability, use only new, genuine Honda parts or their equivalents for repair and replacement.

Maintenance, replacement, or repair of the emission control devices and systems may be performed by any marine engine repair establishment or individual, using parts that are "certified" to EPA standards.

MAINTENANCE SAFETY

Some of the most important safety precautions follow. However, we cannot warn you of every conceivable hazard that can arise in performing maintenance. Only you can decide whether or not you should perform a given task.

AWARNING

Failure to properly follow maintenance instructions and precautions can cause you to be seriously hurt or killed.


Always follow the procedures and precautions in the owner's manual.

Safety Precautions

- Make sure the engine is off before you begin any maintenance or repairs. This will eliminate several potential hazards:
 - Carbon monoxide poisoning from engine exhaust.
 Be sure there is adequate ventilation whenever you operate the engine.
 - Burns from hot parts.
 Let the engine and exhaust system cool before touching.
 - —Injury from moving parts. Do not run the engine unless instructed to do so.


- Read the instructions before you begin, and make sure you have the tools and skills required.
- To reduce the possibility of fire or explosion, be careful when working around gasoline. Use only a nonflammable solvent, not gasoline, to clean parts. Keep cigarettes, sparks, and flames away from all fuel-related parts.
- Wear gloves when handling the propeller to protect your hands from sharp edges.

TOOL KIT AND EMERGENCY STARTER ROPE



EMERGENCY STARTER ROPE

The following tools are supplied with the outboard motor for simple maintenance procedures and emergency repairs. An emergency starter rope is also supplied. Keep these items on the boat, so they will always be available if you need them.



MAINTENANCE SCHEDULE

I	Perform a	R SERVICE PERIOD (3) It every indicated month or hour interval, whichever	Each use	First month or 20 hrs.	Every 6 months or 100 hrs.	Every year or 200 hrs.
• I	Engine oil	Check level	Ö			
	_	Change				
	Gear case oil	Check level			LO	
1 1		Change				
i i		Check for water				
		contamination				
5	Starter rope	Check				
	Carburetor linkage	Check-adjust		O(2)	○ (2)	
• \	Valve clearance	Check-adjust		Q(2)	<u> </u>	<u> </u>
• 8	Spark plug	Check-adjust			0	
		Replace				
F	Propeller (cotter pin)	Check	<u> </u>			•
	Anode	Check	Ţ Ō			
1) •	dle speed	Check-adjust		() (2)	(2)	
I.L	Lubrication	Grease		(1)	○ (I)	
• I	Fuel tank and tank filter	Clean		_ ·		

- · Emission-related items.
 - (1) Lubricate more frequently when used in salt water.
 - (2) These items should be serviced by an authorized Honda marine dealer, unless you have the proper tools and are mechanically proficient. Refer to the Honda shop manual for service procedures.
 - (3) For professional commercial use, log hours of operation to determine proper maintenance intervals.


	Peri ope con	GULAR SERVICE PERIOD (3) form at every indicated month or erating hour interval, whichever nes first.	Each use	First month or 20 hrs.	Every 6 months or 100 hrs.	Every year or 200 hrs.
L.	ITEM					
L	Thermostat	Check				○ (2)
•	Fuel filter	Check		_	/ . <u>.O</u>	
1		Replace .				Q
•	Fuel line	Check	0			·
L		Check (Replace if necessary)		Every 2	years (2)	·
	Bolts and Nuts	Check-tightness	•	O(2)	○(2)	
•	Crankcase breather to	ube Check				O(2)

• Emission-related items.

- (1) Lubricate more frequently when used in salt water.
- (2) These items should be serviced by an authorized Honda marine dealer, unless you have the proper tools and are mechanically proficient. Refer to the Honda shop manual for service procedures.
- (3) For professional commercial use, log hours of operation to determine proper maintenance intervals.

ENGINE COVER REMOVAL AND INSTALLATION

ENGINE COVER LOCK LEVER



The engine cover lock lever fastens the engine cover to the outboard motor.


To remove the engine cover, unlock the engine cover lock lever, then lift the engine cover off the outboard motor.

To install the engine cover, place the cover on the outboard motor, then lock the engine cover lock lever securely.


Engine Oil Level Check

Check the engine oil level with the engine stopped and the outboard motor in the vertical position.

- 1. Unlock and remove the engine cover.
- 2. Remove the dipstick and wipe it clean.



Insert the dipstick all the way in, then remove it and check the oil level shown on the dipstick.



4. If the oil level is low, remove the oil filler cap, and add oil to reach the upper limit mark shown on the dipstick. Use the oil recommended on p. 48.

NOTICE

Running the engine with a low oil level can cause engine damage.


- 5. Install the oil filler cap and tighten it securely.
- 6. Install and lock the engine cover.

Engine Oil Change

An engine oil evacuation/filling device may be used to remove/add the engine oil.

Drain the used oil while the engine is warm. Warm oil drains quickly and completely.

1. Unlock and remove the engine cover (p. 46).



ENGINE OIL DRAIN SCREW

- 2. Remove the oil filler cap, and remove the engine oil drain screw.
- 3. Allow the used oil to drain completely, then reinstall the engine oil drain screw, and tighten it securely.

NOTICE

Improper disposal of engine oil can be harmful to the environment. If you change your own oil, please dispose of the used oil properly. Put it in a sealed container, and take it to a recycling center. Do not discard it in a trash bin or dump it on the ground.


4. With the outboard motor in a vertical position, fill to the upper limit mark on the dipstick (p. 46) with the recommended oil.


Engine oil refill capacity: 1.2 US qt (1.1 \(\ell \), 1.0 lmp qt)

- 5. Install the oil filler cap and tighten it securely.
- 6. Install and lock the engine cover.

Engine Oil Recommendations

Oil is a major factor affecting performance and service life. Use 4-stroke automotive detergent oil.






AMBIENT TEMPERATURE

SAE 10W-30 is recommended for general use. Other viscosities shown in the chart may be used when the average temperature in your area is within the recommended range.

The SAE oil viscosity and service classification are in the API label on the oil container. Honda recommends that you use API SERVICE category SF or SG oil with the "starburst" certification mark displayed on the container.

Gear Oil Level Check

Check the gear oil level with the engine stopped and the outboard motor in the vertical position.



Remove the oil level plug and see whether oil flows from the oil level hole.


If oil flows from the oil level hole, the oil level is OK. Reinstall the plug and tighten it securely.

OIL LEVEL PLUG TORQUE: 4.7 lbf-ft (6.4 N·m, 0.65 kgf·m)

If no oil flows from the oil level hole, add the recommended oil following the procedure described in Gear Oil Change.

Gear Oil Change


Change the gear oil with the engine stopped and the outboard motor in the vertical position.



- 1. Place a suitable container below the oil drain hole to catch the used oil, then remove the oil level plug, and oil drain plug.
- 2. Remove any metal particles from the magnetic end of the oil drain plug.

 Allow the used oil to drain completely, then install an oil pump adapter in the oil drain hole.

If water or contaminated (milky-colored) oil flows out the drain hole when the plug is removed, have the outboard motor checked by and authorized Honda Marine dealer.




4. Add oil through the oil drain hole until it flows out the oil level hole, then install the oil level plug and the oil drain plug.

GEAR OIL CAPACITY: 0.25 US qt (0.24 & , 0.21 Imp qt)

Outboard motor SAE 90 hypoid gear oil API Service classification (GL-4 or GL-5) OIL LEVEL PLUG TORQUE: 4.7 lbf·ft (6.4 N·m , 0.65 kgf·m)

Avoid losing more than 1 fl oz (30 cm³) while reinstalling the drain plug.

OIL DRAIN PLUG TORQUE: 4.7 lbf·ft (6.4 N·m, 0.65 kgf·m)



Apply Honda Marine Corrosion Inhibitor (or equivalent) to all areas under the engine cover except the belts.


Spark Plug Service

RECOMMENDED SPARK PLUGS: DR-6HS (NGK) X20FSR-U (DENSO)

NOTICE


Incorrect spark plugs can cause engine damage.

- 1. Unlock and remove the engine cover (p. 46).
- 2. Disconnect the spark plug caps from the spark plugs.
- Remove the spark plugs with a spark plug wrench and screwdriver supplied in the tool kit.



SPARK PLUG WRENCH

4. Inspect the spark plugs. Replace them if the electrodes are worn, or if the insulators are cracked or chipped. Clean the spark plugs with a wire brush if you are going to reuse them.



5. Measure the spark plug electrode gap with a suitable gauge. The gap should be 0.024 - 0.028 inches (0.60 - 0.70 mm).

- 6. Install the spark plugs carefully, by hand, to avoid cross-threading.
- 7. After each spark plug seats, tighten with a spark plug wrench supplied in the tool kit to compress the sealing washer.

If reinstalling the used spark plugs, tighten 1/8 - 1/4 turn after the spark plugs seat.

If reinstalling new spark plugs, tighten 1/2 turn after the spark plugs seat.

NOTICE

Loose spark plugs can overheat and damage the engine. Overtightening the spark plugs can damage the threads in the cylinder head.

- 8. Attach the spark plug caps.
- 9. Install and lock the engine cover.


REFUELING

Portable Fuel Tank (optional equipment)


FUEL TANK CAPACITY: 3.2 US gal (12 & , 2.6 lmp gal)

Check the fuel gauge and refill the tank when necessary.

Remove the fuel tank from the boat for refueling.



To refuel, turn the vent knob counterclockwise to the OPEN position, and unscrew the fuel tank cap.



Refuel in a well-ventilated area. Fill the tank to the SAFE FILL LEVEL line.

After refueling, install the cap and tighten it securely. Turn the vent knob clockwise to the CLOSED position, and return the fuel tank to the hoat.

AWARNING

Gasoline is highly flammable and explosive.

You can be burned or seriously injured when handling fuel.

- Stop the engine and keep heat, sparks, and flame away.
- Handle fuel only outdoors.
- Wipe up spills immediately.

Never refill the fuel tank inside a building where gasoline fumes may reach flames or sparks. Keep gasoline away from appliance pilot lights, barbecues, electric appliances, power tools, etc.

Spilled fuel is not only a fire hazard, it causes environmental damage. Wipe up spills immediately.

FUEL RECOMMENDATIONS

Use unleaded gasoline with a pump octane rating of 86 or higher.

These outboard motors are certified to operate on unleaded gasoline. Unleaded gasoline produces fewer engine and spark plug deposits and extends exhaust system life.

Never use stale or contaminated gasoline or an oil/gasoline mixture. Avoid getting dirt or water in the fuel tank.

Occasionally you may hear a light "spark knock" or "pinging" (metallic rapping noise) while operating under heavy loads. This is no cause for concern.

If spark knock or pinging occurs at a steady engine speed, under normal load, change brands of gasoline. If spark knock or pinging persists, see an authorized Honda marine dealer.

NOTICE

Running the engine with persistent spark knock or pinging can cause engine damage.

Running the engine with persistent spark knock or pinging is misuse, and the *Distributor's Limited Warranty* does not cover parts damaged by misuse.

Fuel Pump Filter Inspection and Replacement

The fuel pump filter is located under the engine cover, on the right side of the engine.

Water or sediment accumulated in the filter can cause loss of power or hard starting. To prevent engine malfunction, inspect the filter and replace when necessary.


AWARNING

Gasoline is highly flammable and explosive.


You can be burned or seriously injured when handling fuel.

- Stop the engine and keep heat, sparks, and flame away.
- Handle fuel only outdoors.
- Wipe up spills immediately.

ENGINE COVER LOCK LEVER



1. Unlock and remove the engine cover for access to the fuel pump filter.




2. Inspect the filter for water and/or sediment accumulation.

If the filter is OK, reinstall it. If water and/or sediment are present, replace the filter as described in the following steps. Always replace the filter at the scheduled replacement interval (p. 45).


3. Disconnect the fuel hose from the outboard motor, and place clamps on the fuel hoses on each side of the filter to prevent fuel leakage when the fuel hoses are disconnected.





4. Remove the fuel tubes from the used filter, and discard the filter.

To ease tube removal, release the tube clips by squeezing the clip ends together with pliers while pulling off the tubes.




ARROW (Fuel Flow Direction)

- 5. Install the new filter on the fuel hoses, with the fuel flow arrow pointing toward the fuel pump as shown. Fuel flow will be impeded if the filter is installed backward.
- Remove the fuel tube clamps, and connect the fuel hose to the outboard motor. Check for leaks.
- 7. Install and lock the engine cover.


Portable Fuel Tank and Filter Cleaning

Fuel Tank




Empty the portable fuel tank into an approved gasoline container. Use a funnel to avoid spilling fuel. Rinse the fuel tank with nonflammable solvent to remove any accumulated sediment.

Fuel Tank Filter



- Unscrew the fuel hose connector by turning it counterclockwise, then remove the fuel hose connector and fuel filter from the tank.
- 2. Clean the filter in nonflammable solvent. Inspect the fuel tank filter and the connector O-ring. Replace them if damaged.
- 3. Reinstall the filter and hose connector in the fuel tank. Tighten the hose connector securely.


Recoil Starter Rope Inspection



Inspect the recoil starter rope, and replace it if it becomes frayed.

Always keep the emergency starter rope on the boat in case the recoil starter rope fails.

Anode Replacement



The anode is located on the antiventilation plate. It is made of a sacrificial material that helps to protect the outboard motor from corrosion.

Replace the anode when it has been reduced to about half its original size, or if it is crumbling.

NOTICE

Painting or coating the anode will defeat its purpose and will lead to rust and corrosion damage to the outboard motor. The anode must be exposed to the water in order to protect the outboard motor.

Propeller Replacement

Before replacing the propeller, remove the clip from the engine stop switch to prevent any possibility of the engine being started while you are working with the propeller.

The propeller blades may have sharp edges, so wear heavy gloves to protect your hands.

Removal


Remove the cotter pin, unscrew the castle nut, remove the washer, then remove the propeller.

Installation

1. Install the propeller in the reverse order of removal.

NOTICE

• Use a genuine Honda cotter pin and bend the pin ends as shown.



STORAGE

STORAGE PREPARATION

Proper storage preparation is essential for keeping your outboard motor troublefree and looking good. The following steps will help to keep rust and corrosion from impairing your outboard motor's function and appearance, and will make the engine easier to start when you use the outboard motor again.

Cleaning and Flushing

Thoroughly clean and flush the outboard motor with fresh water after operation in dirty water or salt water.

Cleaning


Wash the outside of the outboard motor with clean, fresh water to remove mud, salt, seaweed, etc.

Disengage the emergency engine stop switch clip from the engine stop switch, and pull the recoil starter rope several times to expel any water remaining in the water pump.

Touch up any damaged paint, and coat areas that may rust with a light film of oil. Lubricate controls with a silicone spray lubricant.

Flushing With the Honda Garden Hose Adapter

- 1. Remove the flush bolt from the WASH bolt hole and install the garden hose adapter.
- 2. Attach a hose from a fresh water faucet to the garden hose adapter of the flush kit.
- 3. Remove the propeller.
- 4. Turn on the fresh water supply to the hose.
- 5. Start the engine and run in neutral at idle for at least 10 minutes.




After flushing, remove the

garden hose adapter.

Flushing Without the Honda Garden Hose Adapter

It is necessary to run the engine during the flushing procedure. For safety, remove the propeller from the outboard motor (p. 59).



1. Place a container under the outboard motor, and fill it with clean, fresh water. The water level must be at least 2 inches above the antiventilation plate.

NOTICE

Running the engine without good water circulation can cause overheating and water pump damage.

Damage caused by running the outboard motor without sufficient cooling water is not covered by the *Distributor's Limited Warranty*.

- 2. Start the engine and run in (N) neutral at low speed for at least 10 minutes.
- 3. After flushing, stop the engine, remove the water container, and reinstall the propeller (p. 59).

Fuel

Gasoline will oxidize and deteriorate in storage. Old gasoline will cause hard starting, and it leaves gum deposits that clog the fuel system. If the gasoline in your fuel tank and carburetor deteriorates during storage, you may need to have the carburetor and other fuel system components serviced or replaced.

The length of time that gasoline can be left in your fuel tank and carburetor without causing functional problems will vary with such factors as gasoline blend, your storage temperatures, and whether the fuel tank is partially or completely filled. The air in a partially filled fuel tank promotes fuel deterioration. Very warm storage temperatures accelerate fuel deterioration. Fuel deterioration problems may occur within a few months, or even less if the gasoline was not fresh when you filled the fuel tank.

The Distributor's Limited Warranty does not cover fuel system damage or engine performance problems resulting from neglected storage preparation.

You can avoid fuel deterioration problems by draining the fuel tank and carburetors.

1. Disconnect the fuel hose from the outboard motor.



2. With the outboard motor in a vertical position, place an approved gasoline container below the fuel drain outlet, and use a funnel to avoid spilling fuel.

Loosen the drain screw to drain fuel from the carburetor.

AWARNING

Gasoline is highly flammable and explosive.

You can be burned or seriously injured when handling fuel.

- Stop the engine and keep heat, sparks, and flame away.
- Handle fuel only outdoors.
- Wipe up spills immediately.
- After the fuel has drained from the carburetor, tighten the drain screw securely.

4. Drain the portable fuel tank into an approved gasoline container, or If you need to store fuel in the fuel tank, you can extend fuel storage life by filling the fuel tank with fresh gasoline and adding a fuel stabilizer that is formulated for that purpose. Firmly close the fuel cap vent knob.


STORAGE

Engine Oil

- 1. Change the engine oil (p. 46 47).
- 2. Remove the spark plugs (p. 52), and remove the clip from the engine stop switch.
- 3. Pour a tablespoon (5 10 cm³) of clean engine oil into each cylinder.
- 4. Pull the starter rope several times to distribute the oil in the cylinders.
- 5. Reinstall the spark plugs (p. 53).

STORAGE PRECAUTIONS

Select a well-ventilated storage area. If possible, avoid storage areas with high humidity.




To carry the outboard motor, hold it by the carrying handle, or hold by the carrying handle and the lug beneath the engine cover lock lever, as shown.


NOTICE

Lifting the outboard motor by the engine cover, or using the installed outboard motor as a handle or lever to move the boat, can damage the outboard motor.

If your portable fuel tank contains gasoline, store it away from any appliance that operates with a flame, such as a furnace, water heater, or clothes dryer. Also avoid any area with a spark-producing electric motor, or where power tools are operated.



Store the outboard motor either vertically or horizontally with the tiller handle side up.



If storing horizontally, be sure to fold the tiller handle, and the outboard motor rests on its case protectors. Be sure all water has drained from the outboard motor before placing it on its side, so no residual water can enter the engine exhaust port.

NOTICE

Any other horizontal storage position may cause damage or oil leakage.

Cover the outboard motor to keep out dust. Do not use sheet plastic as a dust cover. A nonporous cover will trap moisture, promoting rust and corrosion.

REMOVAL FROM STORAGE

Check your outboard motor as described in the *BEFORE OPERATION* chapter of this manual.

If the cylinders were coated with oil during storage preparation, the engine may smoke briefly at startup. This is normal.

TRANSPORTING

WITH OUTBOARD MOTOR INSTALLED ON BOAT


When trailering a boat with the outboard motor attached, leave the engine in the normal running position, if possible, and tighten the steering friction bolt securely (p. 37).

If there is insufficient road clearance in the normal running position, then tilt the outboard motor and use a motor support bar, or remove the outboard motor from the boat. Refer to the manufacturer's instructions for using a motor support bar.



WITH OUTBOARD MOTOR REMOVED FROM BOAT

Secure the outboard motor in either the vertical or horizontal position shown on p. 65.



To carry, hold the outboard motor by the carrying handle, or hold by the carrying handle and the lug beneath engine cover lock lever, as shown.

NOTICE

Lifting the outboard motor by the engine cover, or using the installed outboard motor as a handle or lever to move the boat, can damage the outboard motor.

ELECTRIC STARTER WILL NOT OPERATE	Possible Cause	Correction	
1. Check battery.	Battery connections loose or corroded.	Clean and tighten battery connections.	
	Battery discharged.	Recharge battery.	
2. Check fuses.	Fuse(s) burnt out.	Replace fuse(s) (p. 72).	
3. Use emergency starting procedure (p. 32), then take outboard motor to an authorized Honda Marine dealer, or refer to the shop manual.	Starter malfunction, switch malfunction, or electrical problem in the starting circuit.	Replace or repair faulty components as necessary.	

ENGINE WILL NOT START	Possible Cause	Correction	
Check emergency stop switch clip.	Clip not inserted in stop switch.	Insert clip in stop switch.	
2. Check control positions.	Gearshift lever not in neutral position.	Shift to neutral (p. 14).	
	Choke OPEN.	Pull choke knob to CLOSED position, unless engine is warm (p. 13).	
	Throttle grip not in START position.	Turn throttle grip to START position (p. 30).	

ENGINE WILL NOT START (continued)	Possible Cause	Correction
3. Check fuel.	Out of fuel.	Refuel (p. 54).
	Fuel vent closed (portable fuel tank).	Open fuel tank vent (p. 19).
	Fuel hose not primed.	Squeeze priming bulb (p. 29).
	Fuel pump filter or fuel tank filter clogged.	Replace fuel filters (p. 55).
	Bad fuel; boat stored without treating or draining gasoline, or refueled with bad gasoline.	Drain fuel tank and carburetors (p. 62). Refill with fresh gasoline (p. 54).
4. Remove and inspect spark plugs.	Spark plugs faulty, fouled or improperly gapped.	Clean, gap or replace spark plugs (p. 52).
	Spark plugs wet with fuel (flooded engine).	Dry and reinstall spark plugs. Start engine with choke and throttle open.
5. Take outboard motor to an authorized Honda Marine dealer, or refer to the shop manual.	Carburetor malfunction, fuel pump failure, ignition malfunction, stuck valves, etc.	Replace or repair faulty components as necessary.

HARD STARTING OR STALLS AFTER STARTING	Possible Cause	Correction	
1. Check control positions.	Choke OPEN.	Pull choke knob to CLOSED position, unless engine is warm (p. 13).	
	Throttle grip not in START position.	Turn throttle grip to START (p. 30).	
2. Check fuel.	Fuel vent closed (portable fuel tank).	Open fuel tank vent (p. 19).	
	Fuel hose not primed. Fuel pump filter or fuel tank clogged.	Squeeze priming bulb (p. 29). Replace fuel filters (p. 55).	
	Bad fuel; boat stored without treating or draining gasoline, or refueled with bad fuel.	Drain fuel tank and carburetors (p. 62). Refill with fresh gasoline (p. 54).	

HARD STARTING OR STALLS AFTER STARTING (continued)	Possible Cause	Correction
3. Remove and inspect spark plugs.	Spark plugs faulty, fouled or improperly gapped.	Clean, gap or replace spark plugs (p. 52).
4. Take outboard motor to an authorized Honda Marine dealer, or refer to the shop manual.	Carburetor malfunction, fuel pump failure, ignition malfunction, etc.	Replace or repair faulty components as necessary.

ENGINE OVERHEATS	Possible Cause	Correction
1. Check water intake screens.	Water intake screens clogged.	Clean water intake screens.
Take outboard motor to an authorized Honda Marine dealer, or refer to the shop manual.	Faulty thermostat or water pump.	Replace or repair faulty components as necessary.

BATTERY WILL NOT CHARGE AND ELECTRIC STARTER WILL NOT OPERATE

The battery-charging circuit (all models) and the electric starter relay circuit (applicable models) are protected by the 15-ampere fuse. If the fuse burns out, the engine will not charge the battery (all models), and the electric starter (applicable models) will not operate. The engine can be started using the recoil starter or the emergency starter rope.

The ignition switch is protected by the 15-ampere fuse. If the fuse burns out, the engine will not start or run.

Fuse Replacement


1. With the engine stopped, remove the engine cover.

- 2. Remove the fuse holder from the fuse bracket. Pull the rubber cover off the end of the fuse holder, and unscrew the fuse holder cap.
- 3. Remove and inspect the fuses. If a fuse is burnt out, install a replacement fuse of the specified rating. The outboard motor is supplied with spare fuses in the fuse holders.


DESIGNATED FUSE: 15A

NOTICE

Never use a fuse with a rating greater than specified. Serious damage to the electrical system could result.




FUSE HOLDER



4. Reinstall the fuse case lid and the engine cover.

Before further operation, try to determine and correct the electrical problem that caused the fuse to burn out. An uncorrected electrical problem may cause the fuse to burn out again.

OIL PRESSURE INDICATOR LIGHT GOES OFF AND ENGINE SPEED IS LIMITED



If oil pressure becomes low, the green indicator light will go off, and the engine protection system will limit engine speed. If you are at cruising speed, engine speed will decrease gradually.

Low oil pressure may be the result of a low engine oil level, or there may be a problem with the engine lubrication system. If the throttle is closed suddenly after full throttle operation, engine speed may drop below the specified idle rpm, and that could activate the engine protection system momentarily.

If low oil pressure activates the engine protection system, stop the engine, check the engine oil level (p. 46), and add oil if needed.

With the engine oil at the recommended level, restart the engine. If the lubrication system is OK, the green indicator light should come on within 30 seconds, and the engine will respond normally to throttle grip operation.

If the engine protection system remains activated after 30 seconds, return to the nearest boat landing, and have the outboard motor inspected by an authorized Honda marine dealer.


SUBMERGED MOTOR

A submerged outboard motor must be serviced immediately after it is recovered from the water in order to minimize corrosion.

If there is a Honda marine dearship nearby, take the motor to the dealer immediately. If you are far from a dealership, proceed as follows:

- 1. Remove the engine cover, and rinse the outboard motor with fresh water to remove salt water, sand, mud, etc.
- 2. Drain the carburetors as described on p. 62.

3. Change the engine oil as described on p. 47. If there was water in the engine crankcase, or if the used engine oil showed signs of water contamination, then a second engine oil change should be performed after running the engine for half an hour.




4. Remove the spark plugs (p. 52), and remove the clip from the engine switch. Pull the recoil starter grip, rotate the flywheel a few revolutions to completely expel any water from the cylinders.

If the engine was running when it submerged, there may be mechanical damage, such as bent connecting rods. If the engine binds when cranked, do not attempt to run the engine until it has been repaired.

NOTICE

When cranking the engine with an open ignition circuit (spark plugs removed from the ignition circuit), remove the clip from the emergency or engine stop switch to prevent possible damage to the ignition system.



- Pour a teaspoon of engine oil into each spark plug hole, then pull the recoil starter grip several times to lubricate the inside of the cylinders.
- 6. Reinstall the spark plugs, and put the emergency stop switch clip into the switch

7. Attempt to start the engine.

If the engine fails to start, remove the spark plugs, clean and dry them, then reinstall the spark plugs and attempt to start the engine again.


If the engine starts, and no mechanical damage is evident, continue to run the engine for a half hour or longer. Be sure the water level is at least two inches above the antiventilation plate to avoid overheating and water pump damage.

 As soon as possible, take the outboard motor to an authorized Honda Marine dealer for inspection and service.

TECHNICAL INFORMATION

Serial Number Locations


Record the product identification number and engine serial numbers in the space provided on this page. You will need these numbers when ordering parts, and when making technical or warranty inquiries (p. 85).



PRODUCT IDENTIFICATION NUMBER

The product identification number is stamped on a plate attached on the swivel case.

Product identification number:



The engine serial number is stamped on the left front of the crankcase.

Engine serial number:

Carburetor Modification for High Altitude Operation

At high altitude, the standard carburetor air-fuel mixture will be too rich. Performance will decrease, and fuel consumption will increase. A very rich mixture will also foul the spark plugs and cause hard starting.

High altitude performance can be improved by specific modifications to the carburetors. If you always operate your outboard motor at altitudes above 5,000 feet (1,500 meters), have an authorized Honda marine dealer perform this carburetor modification.

Even with carburetor modification, engine horsepower will decrease about 3.5% for each 1,000-foot (300-meter) increase in altitude. The effect of altitude on horsepower will be greater than this if no carburetor modification is made.

NOTICE

When the carburetors have been modified for high altitude operation, the air-fuel mixture will be too lean for low altitude use. Operation at altitudes below 5,000 feet (1,500 meters) with modified carburetors may cause the engine to overheat and result in serious engine damage. For use at low altitudes, have an authorized Honda Marine dealer return the carburetors to original factory specifications.

Oxygenated Fuels

Some conventional gasolines are being blended with alcohol or an ether compound. These gasolines are collectively referred to as oxygenated fuels. To meet clean air standards, some areas of the United States and Canada use oxygenated fuels to help reduce emissions.

If you use an oxygenated fuel, be sure it is unleaded and meets the minimum octane rating requirement.

Before using an oxygenated fuel, try to confirm the fuel's contents. Some states/provinces require this information to be posted on the pump. The following are the EPA-approved percentages of oxygenates:

ETHANOL: ethyl or grain alcohol; 10% by volume.

You may use gasoline containing up to 10% ethanol by volume. Gasoline containing ethanol may be marketed under the name "Gasohol".

MTBE: Methyl Tertiary Butyl Ether; 15% by volume.

You may use gasoline containing up to 15% MTBE by volume.

METHANOL: methyl or wood alcohol; 5% by volume.

You may use gasoline containing up to 5% methanol by volume, as long as it also contains cosolvents and corrosion inhibitors to protect the fuel system. Gasoline containing more than 5% methanol by volume may cause starting and/or performance problems. It may also

damage metal, rubber, and plastic parts of your fuel system.

If you notice any undesirable operating symptoms, try another service station, or switch to another brand of gasoline.

Fuel system damage or performance problems resulting from the use of an oxygenated fuel containing more than the percentages of oxygenates mentioned above are not covered under warranty.

Emission Control System Information

Source of Emissions

The combustion process produces carbon monoxide, oxides of nitrogen, and hydrocarbons. Control of hydrocarbons and oxides of nitrogen is very important because, under certain conditions, they react to form photochemical smog when subjected to sunlight. Carbon monoxide does not react in the same way, but it is toxic.

Honda utilizes lean carburetor settings and other systems to reduce the emissions of carbon monoxide, oxides of nitrogen, and hydrocarbons.

The U.S. and California Clean Air Acts

EPA and California regulations require all manufacturers to furnish written instructions describing the operation and maintenance of emission control systems.

The following instructions and procedures must be followed in order to keep the emissions from your Honda engine within the emission standards.

Tampering and Altering

Tampering with or altering the emission control system may increase emissions beyond the legal limit. Among those acts that constitute tampering are:

- Removal or alteration of any part of the intake, fuel, or exhaust systems.
- Alterations that would cause the engine to operate outside its design parameters.

Problems That May Affect Emissions

If you are aware of any of the following symptoms, have your engine inspected and repaired by your servicing dealer.

- Hard starting or stalling after starting.
- Rough idle.
- Misfiring or backfiring under load.
- Afterburning (backfiring).
- Black exhaust smoke or high fuel consumption.

Replacement Parts

The emission control systems on your Honda engine were designed, built, and certified to conform with EPA and California emission regulations. We recommend the use of genuine Honda parts whenever you have maintenance done. These original-design replacement parts are manufactured to the same standards as the original parts, so you can be confident of their performance. The use of replacement parts that are not of the original design and quality may impair the effectiveness of your emission control system.

A manufacturer of an aftermarket part assumes the responsibility that the part will not adversely affect emission performance. The manufacturer or rebuilder of the part must certify that use of the part will not result in a failure of the engine to comply with emission regulations.


Maintenance

Follow the maintenance schedule on p. 44. Remember that this schedule is based on the assumption that your machine will be used for its designed purpose. Sustained high-load operation, or use in unusual conditions, will require more frequent service.

Star Label

A Star label was applied to this outboard motor in accordance with the requirements of the California Air Resources Board.

The Star Label means Cleaner Marine Engine



The Symbol for Cleaner Marine Engines:

Cleaner Air and Water - for healthier lifestyle and environment.

Better Fuel Economy - burns up to 30 - 40 percent less gas and oil than conventional carbureted two-stroke engines, saving money and resources.

Longer Emission Warranty - protects consumer for worry free operation.



One Star Low Emission

The one-star label identifies engines that meet the Air Resources Board's 2001 exhaust emission standards. Engines meeting these standards have 75% lower emissions than conventional carbureted two-stroke engines. These engines are equivalent to the U.S. EPA's 2006 standards for marine engines.



Two Stars Very Low Emission

The two-star label identifies engines that meet the Air Resources Board's 2004 exhaust emission standards. Engines meeting these standards have 20% lower emissions than One Star-Low-Emission engines.



Three Stars Ultra Low Emission

The three-star label identifies engines that meet the Air Resources Board's 2008 exhaust emission standards. Engines meeting these standards have 65% lower emissions than One Star-Low-Emission engines.

Cleaner Watercraft - Get the Facts 1-800-END-SMOG www.arb.ca.gov

Specifications

MODEL	BF*	15A
Description Code	BAAS	
Type	SA	SAS
Overall length	21.7 in (!	550 mm)
Overall width	12.6 in (3	320 mm)
Overall height	41.3 in (1	,050 mm)
Transom height	17.3 in (4	440 mm)
Weight		101.4 lbs (46.0 kg)
Rated power	11.0 kW	(15 PS)
Full throttle range	5,000 – 6,200 rpm	
Engine type	4 stroke OHC in-line 2 cylinder, water-cooled	
Displacement	17.1 cu-in (280 cm³)	
Spark plug gap	0.024-0.028 in (0.60-0.70 mm)	
Starter system	Recoil starter	Recoil starter &
		Electric starter
Ignition system	C.D.I	
Lubrication system	Trochoid pump pressure lubrication	
Specified oil	Engine: API standard (SF or SG)	
	SAE 10W-30	
	Gear case: API standard (GL4/5) SAE 90	
	outboard r	notor gear <u>oil</u>
Oil capacity	Engine: 1.2 US qt (1.1	l ይ , 1.0 lmp qt)
	Gear case: 0.25 US qt	(0.24 l , 0.21 Imp qt)

CARB star label	VERY LOW EMISSION
D.C. output	12V-6A
Cooling system	Water cooling with thermostat
Exhaust system	Underwater exhaust
Spark plugs	DR-6HS (NGK)
	X20FSR-U (DENSO)
Fuel pump	Diaphragm type fuel pump
Fuel	Automotive unleaded gasoline
	(86 pump octane or higher)
Tank capacity	3.2 US gal (12 ½ , 2.6 lmp gal)
Gear change	Forward-Neutral-Reverse (dog type)
Steering angle	40° right and left
Transom angle	5 stages (4°-8°-12°-16°-20°)
Tilt angle	3 stages adjustment (30°, 45° and 70°)
Standard propeller	9-1/2 $ imes$ 9-1/2 in (3-240 $ imes$ 240 mm)
(No. of blades-	
diameter × pitch)	

Tune Up

I wite ep			
Spark plug gap	0.024 0.028 in		See page 52
	(0.60-0.7)	0 m <u>m)</u>	
Idle speed	$1,100 \pm 50 \text{rpm}$		See shop
			manual
Valve clearance	Intake: 0.12	\pm 0.02 mm	See shop
(cold)	Exhaust: 0.20 :	± 0.02 mm	manual
Other specifications	No other adjustment is needed		

Honda outboards are power rated in accordance with NMMA procedures and using the ICOMIA standard 28/23.

Specifications

MODEL		BF15A		
Description Code	BAAS			
Туре	LA	LAS	XAS	
Overall length		21.7 in (550 mm)	
Overall width		12.6 in (320 mm)	
Overall height	46.5 in (1	,180 mm)	52.0 in	
_			(1,320 mm)	
Transom height	22.4 in (570 mm)	28.0 in	
			(710 mm)	
Weight	95.9 lbs	103.6 lbs	110.2 lbs	
1 2	(43.5 kg)	(47.0 kg)	(50.0 kg)	
Rated power		11.0 kW (15 PS)		
Full throttle range	5,000-6,200 rpm			
Engine type	4 stroke OHC in-line 2 cylinder, water-cooled			
Displacement	17.1 cu-in (280 cm³)			
Spark plug gap	0.024 - 0.028 in (0.60 - 0.70 mm)			
Starter system	Recoil Recoil starter & Electric		er & Electric	
	_starter _	sta	rter	
Ignition system	C.D.I			
Lubrication system	Trochoid pump pressure lubrication			
Specified oil	Engine: API standard (SF or SG)			
1 -	SAE 10W-30			
	Gear case: API standard (GL4/5) SAE 90			
	outboard motor gear oil			
Oil capacity	Engine: 1.2 US at (1.1 & , 1.0 lmp at)			
	Gear case: 0.25 US qt (0.24 g , 0.21 Imp qt)			

CARB star label	VERY LOW EMISSION
D.C. output	12V-6A
Cooling system	Water cooling with thermostat
Exhaust system	Underwater exhaust
Spark plugs	DR-6HS (NGK)
	X20FSR-U (DENSO)
Fuel pump	Diaphragm type fuel pump
Fuel	Automotive unleaded gasoline
	(86 pump octane or higher)
Tank capacity	3.2 US gal (12 & , 2.6 Imp gal)
Gear change	Forward-Neutral-Reverse (dog type)
Steering angle	40° right and left
Transom angle	5 stages (4°-8°-12°-16°-20°)
Tilt angle	3 stages adjustment (30°, 45° and 70°)
Standard propeller	9-1/2 × 8-5/8 in (3-240 × 220 mm)
(No. of blades-	
diameter × pitch)	

Tune Un

Sanda due and	0.004 0.000:	Canada FO
Spark plug gap	0.024-0.028 in	See page 52
	<u>(0.60 — 0.70 mm)</u>	
Idle speed	$1,100 \pm 50 \mathrm{rpm}$	See shop
	_	manual
Valve clearance	Intake: 0.12 ± 0.02 m	m See shop
(cold)	Exhaust: 0.20 ± 0.02 m	m <u>m</u> anual
Other specifications	No other adjustmen	t is needed

Honda outboards are power rated in accordance with NMMA procedures and using the ICOMIA standard 28/23.

CONSUMER INFORMATION

Honda Publications

These publications will give you additional information for maintaining and repairing your outboard motor. You may order them from your Honda marine dealer.

Shop Manual

This manual covers complete maintenance and overhaul procedures. It is intended to be used by a skilled technician.

Parts Catalog

This manual provides complete, illustrated parts lists.

Customer Service Information

Honda Marine dealership personnel are trained professionals. They should be able to answer any question you may have. If you encounter a problem that your dealer does not solve to your satisfaction, please discuss it with the dealership's management. The Service Manager or General Manager can help. Almost all problems are solved in this way.

If you are dissatisfied with the decision made by the dealership's management, contact the Honda Marine Customer Relations Office. You can write:

American Honda Motor Co., Inc.

Marine Division
Customer Relations Office
4900 Marconi Drive
Alpharetta, Georgia 30005-8847


Or telephone: (770) 497-6400

When you write or call, please give us this information:


- Model and serial numbers (p. 76)
- Name of the dealer who sold the outboard motor to you
- Name and address of the dealer who services your outboard motor
- Date of purchase
- Your name, address, and telephone number
- A detailed description of the problem

WIRING DIAGRAM

With Electric Starter



Without Electric Starter



Anode	18
Replacement	58
ARE YOU READY TO GET UNDER WAY?	25
ATTACHMENT	21
BATTERY CONNECTIONS	22
BATTERY WILL NOT CHARGE AND	
ELECTRIC STARTER WILL NOT OPERATE	72
BEFORE OPERATION	25
BOAT TRANSOM REQUIREMENTS	27
BREAK-IN PROCEDURE	20
Carburetor Modification for High Altitude Operation	77
Choke Knob	13
COMMON CONTROLS	15
COMPONENT AND CONTROL LOCATIONS	11
CONSUMER INFORMATION	
CONTROLS	13
CONTROLS AND FEATURE IDENTIFICATION	
CODES	10
CONTROLS AND FEATURES	10
Cooling System Indicator	18
CRUISING	38
Customer Service Information	85

Electric Starter Button (models equipped with	
electric starter)	15
EMERGENCY STARTING	
Emission Control System Information	79
Engine	
Cover	
Lock lever	15
REMOVAL AND INSTALLATION	46
Oil	
Change	47
Level Check	46
Recommendations	48
ENGINE OVERHEARTS	71
Engine Stop Switch and Switch Clip	13
ENGINE WILL NOT START	

Fuel	
Cap Vent Knob	
Gauge	
HOSE CONNECTIONS28	
PRIMING	
Priming Bulb 19	
Pump Filter Inspection and Replacement 55	
RECOMMENDATIONS55	
Tank Filter 57	
Gear	
Oil	
Change	
Level Check48	
GEARSHIFTING AND THROTTLE OPERATION 36	
Gearshift Lever14	
HARD STARTING OR STALLS AFTER	
STARTING 70	

Portable Fuel Tank	19, 28
Portable Fuel Tank and Filter Cleaning	57
POWER REQUIREMENTS	
Propeller Replacement	
Recoil Starter Grip	15
Recoil Starter Rope Inspection	
REFUELING	
REMOVAL FROM STORAGE	

SAFE OPERATING PRECAUTIONS	27
SAFETY LABEL LOCATIONS	9
Serial Number Locations	76
SERVICING YOUR OUTBOARD MOTOR	
SHALLOW WATER OPERATION	39
Spark Plug Service	
Specifications	
Star Label	
STARTING THE ENGINE	
STEERING	
Steering Friction Bolt	
STOPPING THE ENGINE	
Emergency Engine Stopping	
Normal Engine Stopping	
STORAGE	
STORAGE PRECAUTIONS	64
STORAGE PREPARATION	60
Cleaning and Flushing	
Engine oil	
Fuel	
SUBMERGED MOTOR	

TAKING CARE OF UNEXPECTED PROBLEMS	67
TECHNICAL AND CONSUMER INFORMATION	
TECHNICAL INFORMATION	76
THE IMPORTANCE OF MAINTENANCE	
Throttle Friction Knob	14
Throttle Grip	14
Tilt Lever	16
TOOL KIT AND EMERGENCY STARTER ROPI	E 43
Transom Angle Adjusting Rod	16, 27
TRANSOM ANGLE ADJUSTMENT	22
TRANSPORTING	66
WITH OUTBOARD MOTOR INSTALLED	
ON BOAT	66
WITH OUTBOARD MOTOR REMOVED	
FROM BOAT	66
WIRING DIAGRAMS	86
TIME OF DEPONATION OF THE PROPERTY OF THE PROP	60

HONDA The Power of Dreams

