

BREATHER HEATER KITS



Generators

Introduction

Honda generators are designed to operate in cold weather. However, there are some cold-weather conditions where it is possible for condensation to collect and freeze inside the crankcase breather tube between the air cleaner and the engine. When this happens, ice can block the air flow, restricting crankcase ventilation which may cause the generator to run poorly or oil to leak from the engine.

A breather heater will keep the tube warm enough to prevent ice from forming. The breather heater fits inside the tube. The heating coil gets its power from the generator by connecting to the back terminal of a selected receptacle. After the breather heater kit is installed, it may remain on the generator and operate year-round.



Breather Heater Kits

The following kits are available from your local, authorized Honda Power Equipment dealer. To find a dealer near you, visit powerequipment.honda.com, or call Honda Power Equipment Customer Relations at 770-497-6400, option 6.

If your model is not listed below, a breather heater kit is currently not available.

Series	Model	Part No.
EB	EB3000cK1, EB3000cK2	06390-Z04-E20
	EB3800X	06390-Z22-T20
	EB5000XK2	06390-Z22-T20
	EB6500X	06390-Z22-T20
EG	EG2800i	06390-Z43-A30
EM	EM3800SX	06390-Z22-S20
	EM5000is	06390-Z12-R10
	EM5000is1	06390-Z25-V40
	EM5000S XK2	06390-Z22-S20
	EM6500S XK1	06390-Z22-S20
EU	EU1000i, EU1000iK1	06390-ZT3-S10
	EU2000i	06390-Z07-C20
	EU3000i Handi, EU3000iK1 Handi	06150-Z28-C31
	EU3000is, EU3000isK1	06390-ZS9-T20
	EU6500is	06390-Z25-R00
	EU6500is1	06390-Z25-V40
	EU7000is	06390-Z37-A41