

# Honda Hand Held Quick Reference Guide

This guide provides common hand held replacement parts for recent production models.

<b>Model</b>	<b>Type</b>	<b>Prefix</b>	<b>Serial Number Range</b>	<b>Air Cleaner PN</b>	<b>Recoil Starter PN</b>	<b>Spark Plug</b>	<b>Spark Plug PN</b>
HHT25S	All	HAFA	1000001 ~	17211-Z0H-000	28400-Z3E-M01	NGK CMR5H	31915-Z0H-003
HHT35S	LTAT	HAGA	1000001 ~	17211-Z0Z-000	28400-Z3F-M01	NGK CMR5H	31915-Z0H-003
HHT35S	UKAT	HAHA	1000001 ~	17211-Z0Z-000	28400-Z3F-M01	NGK CMR5H	31915-Z0H-003
UMC425A	LAAT	HAGT	1000001 ~	17211-Z0H-000	28400-Z3E-M01	NGK CMR5H	31915-Z0H-003
UMC435A	LAAT	HAHT	1000001 ~	17211-Z0Z-000	28400-Z3F-M01	NGK CMR5H	31915-Z0H-003